



2. External Photograph of the Host

Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)

Notebook Type



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)




Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)

Tablet Type





Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)



**3. Photograph of Accessory for the Host**

Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)

List of Accessory for Host (Notebook Computer):

Specification of Accessory		
AC Adapter	Brand Name	HP
	Model Name	HSTNN-DA40
Battery 1	Brand Name	HP
	Model Name	HSTNN-DB6B
Battery 2	Brand Name	HP
	Model Name	HSTNN-LB6B

Remark: For accessories equipped with this EUT, please refer to the following photos.



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)

AC Adapter



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)

Battery 1



Host: Notebook PC (Brand Name: Hewlett-Packard / Model Name: TPN-C115)

Battery 2

