



xumo STREAM BOX



- 1 Connect the **HDMI cable** between your TV and Xumo Stream Box. Turn your TV on and select the HDMI input for the Xumo Stream Box.
Be sure you have wifi with internet connection.
- 2 Connect the **power adapter** to the device and plug into a power outlet.
- 3 **Remove the battery tab** and point your remote directly toward the front of the device. Follow onscreen instructions.
For the best results, be within 10 feet of the device.




Button Name
Power / Standby
Input Select
Setup
Play/Pause
Mute
Up
Left
Select/OK
Right
Down
Back/Last
Home
Volume Up
Plus
Voice
Volume Down
1
2
3
4
5
6
7
8
9
0


Inserting, removal and replacement of remote control batteries.

⚠ CAUTION : Risk of explosion if batteries are replaced by an incorrect type. Only use AAA alkaline batteries.

- 1 Slide off bottom cover.




- 2 Insert batteries as shown, ensuring correct orientation.




- 3 Replace bottom cover.

In the box




Xumo Stream Box




Voice Remote

2 AAA batteries installed



Power adapter




HDMI cable

Need help? xfinity.com/chat

Learn more about FCC information at
xfinity.com/fcc-compliance-notice


Explore accessibility at
xfinity.com/support/accessibility

xumo STREAM BOX




- 1 Conecta el **cable HDMI** entre tu TV y dispositivo de streaming Xumo. Enciende tu TV y selecciona la entrada HDMI para el dispositivo de streaming Xumo. Asegúrate de que tienes wifi con conexión a internet.
- 2 Conecta el **adaptador de corriente** al dispositivo y a un enchufe eléctrico.
- 3 **Quita la pestaña de las pilas** y apunta tu control remoto directamente hacia la parte delantera del dispositivo. Sigue las instrucciones en pantalla.
Para mejores resultados, ubícate a 10 pies del dispositivo.


En la caja




Dispositivo de streaming Xumo



Control Remoto por voz
2 pilas AAA instaladas



Adaptador de corriente



Cable HDMI

¿Necesitas ayuda? en.xfinity.com/chat

Obtén más información sobre FCC en
en.xfinity.com/fcc-compliance-notice

Explora la accesibilidad en
en.xfinity.com/support/accessibility

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not used in accordance with the instructions, may cause harmful interference to radio communications.

There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase or decrease the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the place of purchase or an experienced remote control/TV technician for help.
- It is strongly recommended that the TV be plugged into a separate wall outlet.

The user is cautioned that changes and modifications made to this equipment without the approval of the manufacturer could void the user's authority to operate this equipment. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Declaración de conformidad de la FCC

Este equipo se ha examinado y se ha comprobado que cumple con los límites establecidos para un equipo digital de clase B, conforme a la parte 15 de las reglas de FCC.

Estos límites se diseñaron para proporcionar una protección razonable contra interferencias perjudiciales en una instalación residencial. Este equipo genera, usa y puede emitir energía de radiofrecuencia y, si no se usa de acuerdo con las instrucciones, puede causar interferencias perjudiciales a las comunicaciones de radio.

No hay ninguna garantía de que la interferencia no ocurrirá en una instalación en particular. Si este equipo causa interferencias perjudiciales a la recepción de la radio o la televisión, se anima al usuario a que intente corregir la interferencia de una o más de las formas ofrecidas a continuación:

- Reorientar o reubicar la antena receptora.
- Aumentar o disminuir la separación entre el equipo y el receptor.
- Conectar el equipo a un enchufe en un circuito diferente al que esté conectado el receptor.
- Pedir asistencia en el lugar de compra o a un técnico de TV y/o controles remotos experimentado.
- Es sumamente recomendable que la TV esté enchufada a una conexión de la pared separada.

Se advierte a los usuarios que los cambios y la aprobación del fabricante podrían invalidar la autoridad del usuario para manejar este equipo. Este equipo se ajusta a la parte 15 de las reglas de la FCC. El funcionamiento está sujeto a las dos condiciones siguientes: (1) Este equipo no puede causar interferencias perjudiciales y (2) este equipo debe aceptar cualquier interferencia recibida, incluso la que pueda causar un funcionamiento indeseado.