

Getting Started Guide

Privacy mode

Microphone off/on

Action

Press and release to talk



Functions

- IR
- RF4CE(IEEE Standard 802.15.4)
- Bluetooth LE 4.2
- Far Field Voice Control

To get started you'll need:



TV and Xfinity TV Box



X1 Voice Remote

xfinity



[Placement illustration goes here]

- 1 Plug in the hands-free remote. Place it in a spot where it has a direct line of sight to the TV
- 2 With your TV on, use your handheld voice remote to say **“Hey xfinity”**
- 3 Follow along on your TV to finish up

Remote features require subscription to Xfinity TV

Guía de inicio

Modo de privacidad

Micrófono off/on

Acción

Presiona y suelta para hablar



Las funciones remotas requieren la suscripción a Xfinity TV con caja de TV X1 elegible y servicio de Xfinity Internet con un Xfinity Gateway compatible

xfinity


Para empezar necesitas:



TV y caja de TV X1



xFi app



Xfinity Gateway inalámbrico


- 1** Descarga y abre la **Xfinity xFi app** en tu equipo móvil e ingresa en la app con tus credenciales de Xfinity.
- 2** Pulsa **Más** en la barra inferior de navegación. Después pulsa **Equipo Xfinity** bajo Agregar un equipo.
- 3** Pulsa **Control remoto de manos libres** y sigue los pasos en pantalla.

Start Here

What's in the box:




Hands-Free Remote




Power adapter

What else you will need:



Xfinity Voice Remote
(handheld)




TV and TV Box
(powered on)




- 1 Plug in your Hands-Free Remote in an open space, where it has a **direct line of sight** to the TV and access to power.

Place it close to where you sit and away from TV speakers.



- 2 Pick up your Xfinity Voice Remote (handheld) and hold down the voice button to say:
"Set up my hands-free remote."




*"Hey Xfinity,
turn my TV on"*

*"Hey Xfinity,
rewind 5 minutes"*

*"Hey Xfinity, show
me The Office"*

*"Hey Xfinity,
WiFi password"*



*"Hey Xfinity, show me
free comedy movies"*

*"Hey Xfinity,
what can I say?"*



Press to turn privacy mode on and off (microphone muting)




Press to use voice control, as an alternative to saying ***"Hey Xfinity"***

Empieza aquí

Qué hay en la caja:




Control remoto de manos libres




Adaptador de corriente

Qué más necesitarás:



Control Remoto por voz de Xfinity
(operado con la mano)




TV y caja de TV
(conectados)


xfinity

- 1 Enchufa tu control remoto de manos libres en un lugar abierto, donde esté en una **línea de visión despejada** hacia el televisor y acceso a electricidad.

Ubícalo cerca de donde te sientes y lejos de los altavoces del televisor.



- 2 Toma tu Control Remoto de Xfinity (operado con la mano) y mantén pulsado el botón de voz para decir:
"Configurar mi control remoto de manos libres".




*"Hey Xfinity,
enciende el televisor"*

*"Hey Xfinity,
retrocede 5 minutos"*

*"Hey Xfinity, quiero ver
La rosa de Guadalupe"*

*"Hey Xfinity,
contraseña de WiFi"*



*"Hey Xfinity, muéstrame
películas gratis"*

*"Hey Xfinity,
¿qué puedo decir?"*



Presiona para activar y desactivar el modo de privacidad
(silenciador del micrófono)



Presiona para usar el control por voz, como alternativa
a decir **"Hey Xfinity"**

1. Part15.19

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

IC

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

2. Part15.21

WARNING: This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause Harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

3. Part15.105

For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with minimum 20 cm between the radiator and your body.
Cet appareil doit être installé et utilisé avec un minimum de 20 cm entre le radiateur et votre corps.

4. SDoC information :

=====

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information
Unique Identifier: XR19-RQ
Responsible Party – U.S. Contact Information
Company: Comcast Corporation
Street Address : 1701 JEK Boulevard
City, State : Philadelphia, PA
Zip Code : 19103
Contact information : +1 267 441 8185

5. Information of authentication

FCC ID: TX4XR19RQ

IC : 11438A-XR19RQ