



T100 ANC



Please read the Important Safety Information for the proper use of this product. After reading, store this User Manual in a place easily accessible to all users.


Images may differ in appearance from the actual product. Contents subject to change without prior notice.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.


CAUTION
Make sure authentic components are used. Using a non-authentic component may damage the product and thus void the warranty. Actual product design may differ from images shown in manual.




Earbuds



Charging case



Wearing Earbuds




You can use ear gels that fit your ears to improve Active Noise Cancelling (ANC) performance and enjoy rich music sound.

When you wear the earbuds, you will hear a wearing detection alarm.

Active Noise Cancellation (ANC)

The Active Noise Cancellation(ANC) function blocks any ambient sound. So, you can use the function to listen to the music or watch a video without interference.




* Notice : ANC is an acronym for Active Noise Cancellation

Warning : When the moment of activation Ambient, You may suddenly hear a loud ambient sound. Be careful about hearing damage. When the moment of activation ANC, You can't hear ambient sounds. Be sure your safety before activating ANC.

Listen to the Ambient Sound (Ambient)


The Listen to the Ambient Sound (Ambient) function allows you to listen to the ambient sound so that you can recognize the surrounding situation and any potential risks.



Touch and hold the left or right ear to switch between the ANC mode and the Ambient mode. You can set up ANC, Ambient function on Mate Application. If you use the Ambient or ANC functions, the battery consumes faster, reducing the time you can use the product.

Wired Charging


When earbuds are fully discharged, they need to be charged for at least 20 minutes. Place earbuds in the appropriate slots inside charging case.



The earbuds and charging case charge simultaneously.

Wireless Charging


Align the bottom center of the charging case with the center of the wireless charger.



NOTE : The wireless charger is not provided. The wireless charging function may not work in some wireless chargers. Wireless charging feature charges at a slower rate due to less power being transmitted to the charging case.


Case LED Charging Indicator

If earbuds are mounted in the charging case, the earbuds' battery status is displayed. Otherwise, the charging case's battery status is displayed.



- LED Indicator of Earbuds**
- Red : Low Battery
 - Yellow : Medium battery
 - Green : High Battery
- LED Indicator of Charging case**
- Red blinking : Charging Case battery very low. Charging Case needs to be charged.
 - Red : Low battery
 - Yellow : Medium battery
 - Green : High Battery


1 Connection



How to pair

- Turn on the Bluetooth function on the mobile phone or the device to be connected. Open the cover of the charging case with the earbuds mounted on the case. Press and hold the touchpad of the left or right earbud for 3 to 5 seconds until the battery status indicator blinks in blue.


* After initial pairing, the earbuds will automatically reconnect to the previously connected devices when turned on.



- The earbuds will disconnect from connected device once they are placed back into charging case and cover is closed.

Device Bluetooth Configuration

Android / iOS



Settings



Bluetooth® Settings



Scan Devices




Pair Device



Single or Dual Pairing




2 Operation of touchpad



Answer / End call

Single tap the earbud(L) or (R) to Answer.




Double tap the earbud(L) or (R) to end call.




Reject call

Press earbud(L) or (R) for 2 second to reject a call (In-ear state)





Play / Pause music

Single tap the earbud(L) or (R) to play/pause music.





Next song / Previous song

Triple tap the earbud(R) to play next song. (Available only when wearing both earbuds.)



Volume up/ Volume down

Double tap the earbud(R) for volume up. (Available only when wearing both earbuds.)



*Music is paused when both earbuds are removed from user's ears.


Triple tap the earbud(L) to play previous song. (Available only when wearing both earbuds.)

Double tap the earbud(L) for volume down. (Available only when wearing both earbuds.)

Connecting to Other Devices

Pairing Mode


Open the cover of the charging case with the earbuds mounted on the case. Press and hold the touchpad of the left or right earbud for 3 seconds. The charging case LED will flash when in pairing mode.



If pairing is not completed within 3 minutes, the earbuds will automatically exit from pairing mode. To re-enter pairing mode, follow the above pairing procedures.

How to Reset

- Open the cover of the charging case with the earbuds mounted on the case.
- Press and hold the touchpad of the left or right earbud for 10 seconds.
- When entering factory reset mode, the charging case LED indicator flashes green twice, then keep flashes Red.
- After successful factory reset, it will automatically enter pairing and the charging case LED flashes green.



Use when the right/left earbuds are not connected to each other and there is an error in the earbuds operation, or when you want to erase all connected device information

CAUTION

- Do not disassemble, adjust, or repair the product arbitrarily.
- Do not use a damaged charger.
- Do not place the product near excessive heat or flammable material.
- Do not arbitrarily replace the battery, as it may explode.
- The product may be damaged if an incompatible charger is used.
- Make sure that an infant or child does not swallow a magnet or a small component of the product.
- Make sure that foreign objects do not enter the charger's connectors (charging port and power plug).
- Failure to do so may result in fire or electric shock.
- For your safety, do not wear the product while it is being charged.
- If you have a medical device implanted, contact your doctor before using this device.
- Do not pull the earphone cable with excessive force.
- For your safety, do not remove the battery incorporated in the product.
- The lithium-ion polymer battery is a hazardous component which can cause injury.
- Battery replacement by an unqualified professional can cause damage to your device.
- If the product is exposed to excessive sweat, clean the product.
- Make sure to keep the earbuds clean at all times.
- Make sure to clean sweat and liquid before charging to prevent corrosion on the earbuds.
- Using a power source other than the charger, such as a computer and auxiliary battery, may result in a slower charging speed due to a lower electric current.
- The product may be heated when it is being charged. This is normal and product will stop charging if the battery's temperature rise over the threshold.
- Contact customer service if products are not charging properly.
- Do not use a damaged charger.
- Do not apply excessive force to the product.
- Do not wear the earbuds in your ears without earbuds.
- Do not pull the earbud with excessive force.
- Do not apply excessive pressure to the touchpad with your fingertips.
- Make sure to tap the touchpad with sharp object.
- Do not store or use the product at extremely high or low temperatures.

WARNING

- Canal type earphones may cause inflammation when used for a long time or worn dirty (dust, sweat, etc.) on them.
- Do not drop the product from a high place.
- Make sure there is no water, alcohol, or benzene in contact with the product.
- Do not store the product in a wet or dusty place.
- Do not place heavy objects on the product.
- It is not waterproof and should not be submerged in water. (Product is sweat and water resistant IPX4.)
- Make sure that infant, child and pet does not swallow, suck or put in mouth.
- Do not wear the earbuds in high-traffic areas, such as roads or crosswalks. Doing so may result in accidents due to slowed reaction times.
- Do not wear earbuds in driving for your safety.
- The headset contains magnets in its earbuds.
- The American Heart Association (USA) and the Medicines and Healthcare Products Regulatory Agency (UK) both warn that magnets can affect the operation of implanted pacemakers, cardioverters, defibrillators, insulin pumps or other electro medical devices collectively.

"Medical Device" within the range of 15 cm (6 inches). If you are a user of any of these Medical Devices, DO NOT USE THE HEADSET UNLESS YOU HAVE CONSULTED WITH YOUR PHYSICIAN. Do not store your headset near magnetic fields. Magnetic stripe cards, including credit cards, phone cards, passbooks, and boarding passes, may be damaged by magnetic fields.

- Avoiding hearing damage
Permanent hearing loss may occur if you use your headset at a high volume.
Set the volume to a safe level. Over time you can become accustomed to a higher volume that may sound normal but can be damaging to your hearing.
If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked.
The louder the volume, the less time that is required before your hearing could be affected.

- Using headsets safely
Use of headsets to listen to music while operating a vehicle is not recommended and is illegal in some areas. Be careful and attentive while driving. Stop using this device if you find it disruptive or distracting while operating any type of vehicle or performing any other activity that requires your full attention.

REGULATORY INFORMATION

FCC NOTICE TO USERS:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the manufacturer (or party responsible for compliance) could void the user's authority to operate the equipment.

FCC Part 15.105 statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
IMPORTANT NOTE:
To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void the user's authority to operate the device.

ADDITIONAL INFORMATION

Bluetooth® connection precautions
- To avoid problems when connecting your headset to another device, place the devices close to each other.
- Ensure that your headset and the other Bluetooth® device are within the Bluetooth® connection range (10 m).
The distance may vary depending on the environment the devices are used in.
- Ensure that there are no obstacles between the headset and a connected device, including human bodies, walls, corners, or fences etc.

- If equipment using 2.4GHz frequency nearby, it may cause interference.
Potentially explosive atmosphere
Turn off your electronic device when in any area with a potentially explosive atmosphere. Although this is uncommon, your electronic device could generate sparks. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Areas with a potentially explosive atmosphere are often but not always clearly marked.
Emergency calls
This Bluetooth® headset and the electronic device connected to it headset, operate using radio signals and mobile and landline networks, as well as user-programmed functions, which cannot guarantee connection under all conditions. Therefore you should never rely solely upon any electronic device for essential communications (e.g., medical emergencies). Remember, in order to make or receive calls, the headset and the electronic device connected to the headset must be switched on and in a service area with adequate mobile signal strength. Emergency calls may not be possible on all mobile phone networks or when certain network services and/or phone features are in use. Check with your local service provider.
the battery to extreme temperatures, never above +50°C (+122°F) or below -10°C (+14°F). For maximum battery capacity, use the battery at room temperature. If the battery is used in low temperatures, the battery capacity will be reduced. The battery can only be charged in temperatures between +10°C (+50°F) and +45°C (+113°F).
The battery is consumable and the useful charge will get shorter over time.
This device was tested in compliance with FCC RF Exposure limit, (0 mm distance from human head/body (limit 1.6 W/kg @ 1g SAR) and extremely (limit 4.0 W/kg @ 10g SAR)).

SPECIFICATION

Bluetooth® specification Ver 5.2

Profiles HSP/ HFP/ A2DP/ AVRCP

Battery Charging case : 410mAh Lithium-ion polymer

Earbud : 60mAh Lithium-ion polymer

RCV Dynamic 8mm Driver

Play time Up to 8 hours(ANC OFF), Up to 7 hours(ANC ON) 16 additional hours with Charging case

Rated input voltage Charging case : 5V 500mA

Earbud : 5V 120mA

Noise control 3Mics Hybrid Active Noise Cancelling

Splash & Sweat Resistant (IPX4)

FCC ID : U3W100ANC

Duration if use may vary depending on the connected device, features being used, settings, signal strength, operating temperature, frequency band, and other method of use.

Standard Limited Warranty

Bluecom declares product warranty as described in the user manual. The warranty period starts from the date of purchase. If the purchase date has not been identified, warranty period will be counted three months after the date of manufacture.

Subject and Warranty Period

1. Main unit, USB cable, Free of charge warranty period 1 year from date of purchase
2. Packing box, user manual, etc., are not guaranteed to be replaced

What is not covered under warranty?

This Limited Warranty is conditioned upon proper use of the Product. This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abnormal use, abnormal conditions, improper storage, exposure to liquid, moisture, dampness, sand or dirt, neglect, or unusual physical, electrical or electromechanical stress; (b) scratches, dents and cosmetic damage, unless caused by BLUECOM; (c) defects or damage resulting from excessive force; (d) equipment that has the serial number or the QR code removed, defaced, damaged, altered or made illegible; (e) ordinary wear and tear; (f) defects or damage resulting from the use of Product in conjunction or connection with accessories, products, or ancillary/peripheral equipment not furnished or approved by BLUECOM; (g) defects or damage resulting from improper testing, operation, maintenance, installation, service, or adjustment not furnished or approved by BLUECOM, including but not limited to installation of unauthorized software and unauthorized root access, both of which shall void this limited warranty; (h) defects or damage resulting from external causes such as collision with an object, fire, flooding, dirt, windstorm, lightning, earthquake, exposure to weather conditions, theft, blown fuse, or improper use of any electrical source; (i) defects or damage resulting from cellular signal reception or transmission, or viruses or other software problems introduced into the Product; or (j) Product used or purchased outside the United States. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if the battery has been charged by a battery charger not specified or approved by BLUECOM for charging the battery.

How to obtain Warranty Service

To obtain service under this Limited Warranty you must return the Product to BLUECOM's designated location in an adequate container for shipping, accompanied by the sales receipt or comparable proof of sale showing the original date of purchase by the first consumer purchaser, the serial number of the Product and the seller's name and address. To obtain assistance in where to deliver the Product, please E-mail BLUECOM support desk at support@blue.co.kr. If BLUECOM determines that any Product is not covered by this Limited Warranty, you must pay all parts, shipping, and labor charges for the repair or return of such Product.

Bluecom Co., Ltd
116, Venture-ro Yeonsu-gu Incheon-city, South Korea 22013