



6.5 Setup Photographs:

13.56 MHz RFID (NTD-Touchscreen), 9 kHz- 30 MHz, Antenna on X-axis



13.56 MHz RFID (NTD-Touchscreen), 9 kHz- 30 MHz, Antenna on Y-axis




13.56 MHz RFID (NTD-Touchscreen), 9 kHz- 30 MHz, Antenna on Z-axis



13.56 MHz RFID (NTD-Touchscreen), 30-1000 MHz



13.56 MHz RFID (NTC-Touchscreen), 9 kHz- 30 MHz, Antenna on X-axis



13.56 MHz RFID (NTC-Touchscreen), 9 kHz- 30 MHz, Antenna on Y-axis



13.56 MHz RFID (NTC-Touchscreen), 9 kHz- 30 MHz, Antenna on Z-axis



13.56 MHz RFID (NTC-Touchscreen), 30-1000 MHz

