SHARPER IMAGE®

ALL-TERRAIN RACE CAR
RC DIRT RODDER

▲ RECHARGEABLE BATTERY AND 9.6V BATTERY CHARGER

◀ FULL FUNCTION REMOTE

FEATURES
- HYPER-SPEED RACING ON ANY TERRAIN
- OVERSIZED KNOBBY TIRES AND 4-WHEEL SUSPENSION
- FULL FUNCTION WIRELESS REMOTE
- 2.4 GHZ ALLOWS FOR MULTIPLE VEHICLE RACING

Car requires one NiMH rechargeable battery pack (included) and one 9V battery (included). See bottom panel for complete operating instructions. Colors and styles may vary.

READY TO RUN!
ALL BATTERIES INCLUDED
RECHARGEABLE DESIGN FOR HIGH PERFORMANCE

SUPER GRIP TIRES
FOR FAST RACING

FULL FUNCTION REMOTE CONTROL

ALL-TERRAIN RACE CAR
RC DIRT RODDER

BATTERY INSTALLATION

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Operation requires one NiMH rechargeable battery pack (included) for car and one 9V battery (included) for radio controller.

- Carefully remove items from package.
- Locate the battery compartment on the bottom of the vehicle.
- Loosen the screw on the bottom of the car to open the battery cover and connect the battery pack.
- Replace the battery compartment door.
- Slide open the battery compartment door of the controller.
- Insert the one 9V battery following the correct polarity.
- Replace the battery compartment door.



NOTE: For best operation, use on a hard surface.

BASIC CAR OPERATION

FORWARD

BACK UP

RIGHT TURN

LEFT TURN

STEERING ALIGNMENT ADJUSTMENT:

To fine-tune the steering control, locate the alignment switch on the underside of the chassis. Starting with the lever in the middle position, test drive your car and adjust as needed. Should the car pull to the left or right, simply move the lever until your car drives straight without touching the directional controller.



SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Never operate your car in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
- Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave car or transmitter outside overnight. Dampness is harmful to interior components.
- Remove all batteries when not in use to avoid accidnetal operation.
- Adult supervision is recommended when operating this car.

BATTERY WARNING:
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
- Remove batteries when not in use. Recycle or dispose of exhausted batteries according to federal, state, and local laws. Do not dispose of batteries in a fire - they may leak or explode.
- Only use manufacture specified battery(ies), charger(s) and/or adapter, if applicable, specified by the manufacturer.
- Always use, replace, and recharge (if applicable) batteries under adult supervision.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

SAFETY WARNINGS - PLEASE READ BEFORE USING PRODUCT
- Not recommended for children under 6 years of age. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electrical shock.
- Inspect the product before every use. If the product appears damaged in any manner, discontinue use and discard immediately.

1002542 (2303623)

6 94202 32646 6
Made in China

©2017 Sharper Image.
Sharper Image® name and logo are registered trademarks.
All rights reserved.
Distributed by MerchSource, LLC. Irvine, CA 92618.
PATENT PENDING
For technical support, please call 1-800-374-2744.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

0-3

BC

SHARPER IMAGE®

ALL-TERRAIN RACE CAR
RC DIRT RODDER

READY TO RUN!
ALL BATTERIES INCLUDED
RECHARGEABLE DESIGN FOR HIGH PERFORMANCE

2.4 GHz
RACE MULTIPLE VEHICLES
COMPETITIVE RACING
LONG DISTANCE RACING WITH QUICK RESPONSE RC

UP TO
12 MPH
ACTUAL SPEED!

WIRELESS RC ACTION!

SHARPER IMAGE®

ALL-TERRAIN RACE CAR RC DIRT RODDER

恒盛玩具: 90.5*56.4
编号: HSWJ-0169
日期: 2017.5.17
SI版
红色为暗线

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ **WARNING! CHOKING HAZARD -**
Small parts. Not suitable for children under 3 years.

SHARPER IMAGE®

ALL-TERRAIN RACE CAR
RC DIRT RODDER

ART DEPARTMENT

Job # / Filename		Product Line	
2017-04-24_SI_ToyRCHobbyLiteDirtRodder12MPH_WhtOra_BlkLim_TESTING		Sharper Image	
Designer Jack Ma	**Brand Manager** Lisa Nagamoto	**Finished Size** 20" L x 9.33" H x 11.28" D / 51cm L x 23.7cm H x 28.7cm D	
File Format Adobe Illustrator CC (live)/CS4 (OL)	**Fonts** Avenir Book, Medium	**Color (Spot or 4C)** 4 Color Process	**# of Colors** 4
Printing Process / Finishing Gloss PP Coating		**Comments**	

MerchSource

All copyright, trademark and patent rights or any other intellectual property rights or material associated with the content provided herein, and the selection, coordination and arrangement of such content, are owned exclusively by MERCHSOURCE LLC., or any third-p licensors. The use or misuse of any copyrights, trademarks, patents or any other intellectual property or materials, except as permitted herein, is expressly prohibited. Any infringements shall be prosecuted to the fullest extent of the law, both foreign and domestic.