























TITLE	S3C2440X - 2
SHEET	2 of 5



위치



TITLE	FM & AUDIO & KEY & LCD
SHEET	4 of 5



TITLE	POWER
SHEET	5 of 5