



...Wireless communication.....

Contents

Contents

Introduction.....	2
Headset feature.....	3
Charging.....	4
Wearing the headset.....	4
Turning the headset on.....	5
Turning the headset off.....	5
Pairing the headset.....	6
Making a call.....	6
Redial the last number.....	7
Ending a call	7
Answering a call.....	7
Rejecting a call.....	8
Adjusting the volume.....	8
Muting the volume.....	8
Transferring a call between the headset and the mobile phone.....	9

Transferring a call between the headset and the mobile phone

1. During a call, press and hold the **VOL+** button for 3 seconds to transfer the call to mobile phone.
2. Press the **VOL+** button again; the call will be transferred to headset.

*The above function is available only after the headset is paired with the mobile phone.

Introduction

The Bluetooth technology is a standard for wireless short distance radio communications. Devices like headset, mobile phone or PDA can communicate with each other without wires within approximately 10 meters. The Tendystar E2 headset is a wireless headset based on the Bluetooth technology. It supports two profiles: Headset profile and Hands-free profile. It will work with any qualified Bluetooth device (including headset or PDA) that supports the Headset profile or Hands-free profile. It also will allow you to take a call and adjust the volume without touching your mobile phone.

9

2

Headset feature



In the package

Headset, Travel charger, Manual

Rejecting a call

Press and hold the **TALK** button for 3 seconds when the headset is ringing.

Adjusting the volume

Press the **VOL+** button to increase the volume and press the **VOL-** to decrease the volume.

Muting the volume

Press and hold **VOL+** button and **VOL-** button for 3 second until you hear a beep. To end the mute function, press the **VOL+** button and **VOL-** button until you hear a beep.

3

8

Redial the last number

Press and hold the **VOL-** button about 3 seconds.

Ending a call

To end a call, press the **TALK** button during a call.

Answering a call

Once you hear an incoming call ring in the headset, press the talk button.

Charging

At the first time, you must fully recharge it for about 8 hours until the blue indicator light turns on. For the subsequent charges, the charging will only take about 2 hours. During the charge, both red and blue indicator lights turn to red. The indicator light will turn to blue when the charge is finished. While the battery is under-power, the indicator light will turn on; at last the indicator light will turn to blue.

*Be sure charging the battery with the supplied charger. *Not allow the charging time more than 12 hours.

Wearing the headset

E2 is tied with a nice neck strap. During calling, wear the headset on the ear, without calling, it looks like a beautiful decoration hung on your neck.

7

4

Using the headset

Turning the headset on

Press and hold the **TALK** button for 3 seconds, then the blue indicator light flashes rapidly.

Turning the headset off

Press and hold the **TALK** button for 3 seconds, then the indicator light turn to red and flashes rapidly.

Pairing the headset

Pairing is the connection between two Bluetooth devices to exchange data. The steps as follows:

1. Press and hold the **TALK** button about 6 seconds until the indicator light flashes red and blue alternatively. Now, the headset is pairing mode.
2. With your mobile device, search for the headset TDSTAR-E2.
3. Enter the headset passkey of 0000.
4. The Tendystar-E2 Bluetooth headset will now ready to use with your mobile device.

Making a call

Dial a phone number on the mobile phone. If your mobile phone offers the voice recognition feature, you could make a call directly from the headset. Press the **TALK** button and say one of your recorded voice tags.

*Make sure the voice tags have been recorded into the mobile phone.

5

6

FCC Caution

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna
--Increase the separation between the equipment and receiver
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
--Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

FCC Notes:

The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

CE Caution:

Hereby, Guangzhou Tendystar Telecom Co., Ltd., declares that this Bluetooth Headset (Intended use/Category: Wideband Data Transmission systems) is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

A copy of the DoC may be obtained through the following address:
Rm1701-1702, New Century Commercial Trade Center, No 2-6 HongDe Load, Guangzhou, China