

材质105G双铜 按裁片折页

折页方式为 风琴折 黑白印刷

360*84mm,

正面

SX-133 Neckband wireless speaker User Manual Thank you for purchasing our product. To ensure optimal performance, please read this manual carefully. This manual will guide you through the use of the SX133 product. <td> For user' s safety, please read this manual before using the speaker. The following matters should be paid attention to when using speaker: Long term use high volume of speaker will damage hearing Please adjust the volume at a comfortable level to use this product Please turn down the volume of the product, and then wear or put it around the ear to test and adjust the optimal comfortable listening state Please avoid long-time use of high volume mode, because it will lead to hearing loss caused by noise. If you are in bad condition of potential danger, please stop using speaker, in order to ensure safety. Users should reasonably control the volume and time when listening to the speaker. The volume should not be too high,otherwise you can' hear the voice around. If volume is too high that may appear tinnitus, please lower down the volume. Don't listen to the music while driving. Use dry soft cloth to clean the speaker! Should avoid the speaker into the water, that will cause speaker damage. <td> If you feel obvious discomfort, stimulation, or other adverse reaction stop using it immediately . The speaker should not be stored or used in temperature below -15°C(5°F) or higher than 55°C(131°F),otherwise will reduce the battery life. Charging and Battery: Please charge the speaker with original charging cable, it may damage the battery or the speaker if you are using improper charging cable. This speaker has built-in rechargeable battery, so do not attempt to remove the battery from the speaker to avoid damaging it. The battery (battery pack or combination) must not be exposed to conditions such as sunlight, fire, or similar overheating. If the battery is not properly replaced, there is a danger of explosion and it can only be replaced with a battery of the same type or equivalent. <td> FCC Requirement Changes or modifications not explicitly approved by the party responsible for compliance may invalidate the user' s authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. <td> Headset button description 1 Volume + / Next 2 Volume - /Previous 3 Multifunctional Button (MFB) 4 LED Indicator 5 charging port <td> Power On/OFF Power on Long press 3 's power On Blue and red light flashes alternately Power OFF Long press 5 's power OFF The red light stays on for 1 second </td></td></td></td></td>	For user' s safety, please read this manual before using the speaker. The following matters should be paid attention to when using speaker: Long term use high volume of speaker will damage hearing Please adjust the volume at a comfortable level to use this product Please turn down the volume of the product, and then wear or put it around the ear to test and adjust the optimal comfortable listening state Please avoid long-time use of high volume mode, because it will lead to hearing loss caused by noise. If you are in bad condition of potential danger, please stop using speaker, in order to ensure safety. Users should reasonably control the volume and time when listening to the speaker. The volume should not be too high,otherwise you can' hear the voice around. If volume is too high that may appear tinnitus, please lower down the volume. Don't listen to the music while driving. Use dry soft cloth to clean the speaker! Should avoid the speaker into the water, that will cause speaker damage. <td> If you feel obvious discomfort, stimulation, or other adverse reaction stop using it immediately . The speaker should not be stored or used in temperature below -15°C(5°F) or higher than 55°C(131°F),otherwise will reduce the battery life. Charging and Battery: Please charge the speaker with original charging cable, it may damage the battery or the speaker if you are using improper charging cable. This speaker has built-in rechargeable battery, so do not attempt to remove the battery from the speaker to avoid damaging it. The battery (battery pack or combination) must not be exposed to conditions such as sunlight, fire, or similar overheating. If the battery is not properly replaced, there is a danger of explosion and it can only be replaced with a battery of the same type or equivalent. <td> FCC Requirement Changes or modifications not explicitly approved by the party responsible for compliance may invalidate the user' s authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. <td> Headset button description 1 Volume + / Next 2 Volume - /Previous 3 Multifunctional Button (MFB) 4 LED Indicator 5 charging port <td> Power On/OFF Power on Long press 3 's power On Blue and red light flashes alternately Power OFF Long press 5 's power OFF The red light stays on for 1 second </td></td></td></td>	If you feel obvious discomfort, stimulation, or other adverse reaction stop using it immediately . The speaker should not be stored or used in temperature below -15°C(5°F) or higher than 55°C(131°F),otherwise will reduce the battery life. Charging and Battery: Please charge the speaker with original charging cable, it may damage the battery or the speaker if you are using improper charging cable. This speaker has built-in rechargeable battery, so do not attempt to remove the battery from the speaker to avoid damaging it. The battery (battery pack or combination) must not be exposed to conditions such as sunlight, fire, or similar overheating. If the battery is not properly replaced, there is a danger of explosion and it can only be replaced with a battery of the same type or equivalent. <td> FCC Requirement Changes or modifications not explicitly approved by the party responsible for compliance may invalidate the user' s authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. <td> Headset button description 1 Volume + / Next 2 Volume - /Previous 3 Multifunctional Button (MFB) 4 LED Indicator 5 charging port <td> Power On/OFF Power on Long press 3 's power On Blue and red light flashes alternately Power OFF Long press 5 's power OFF The red light stays on for 1 second </td></td></td>	FCC Requirement Changes or modifications not explicitly approved by the party responsible for compliance may invalidate the user' s authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. <td> Headset button description 1 Volume + / Next 2 Volume - /Previous 3 Multifunctional Button (MFB) 4 LED Indicator 5 charging port <td> Power On/OFF Power on Long press 3 's power On Blue and red light flashes alternately Power OFF Long press 5 's power OFF The red light stays on for 1 second </td></td>	Headset button description 1 Volume + / Next 2 Volume - /Previous 3 Multifunctional Button (MFB) 4 LED Indicator 5 charging port <td> Power On/OFF Power on Long press 3 's power On Blue and red light flashes alternately Power OFF Long press 5 's power OFF The red light stays on for 1 second </td>	Power On/OFF Power on Long press 3 's power On Blue and red light flashes alternately Power OFF Long press 5 's power OFF The red light stays on for 1 second
--	--	---	--	--	--

反面

Connect with mobile phone 1.The speaker automatically enters pairing mode after powering on, indicated by the red and blue lights flashing alternately. 2. Turn on your Bluetooth device on your mobile phone. 3. From the Bluetooth search menu, select "SX133" and tap to complete the connection. Remarks: 1.If you return within 5 minutes after going out of connection range, the speaker will automatically reconnect. 2.Upon powering on, the speaker automatically attempts to reconnect to previously paired devices; if reconnection fails, it enters pairing mode. <td> Connect with two phones 1. Turn off the Bluetooth function on the connected phone, and the speaker will automatically enter pairing mode. Blue and red light flashes alternately 2.Connect with second mobile phone Choose SX133 gets connected 3.Turn on phone 1 Bluetooth and select SX133 gets connected Phone 1 connects <td> Managing Music Music Control Play/Pause Short press previous Long press - button to select previous song next track Long press + button to select next song Increase volume Short press + button to increase volume decrease volume Short press - button to decrease volume Management Calls Answer/ Hang up Short press to answer / end call reject call Long press 1 second Smart voice Double tap to activate Smart Voice. <td> Restore to factory settings If the speaker cannot enter pairing mode or fails to connect, please restore to factory settings. While powered on Press and hold both buttons for 5 seconds. Red and blue lights stay on simultaneously. Wait for the lights to turn off to complete the operation. <td> Charging procedure 1.Open the USB charging port cover. 2.Insert the smaller end of the USB charging cable into the speaker. 3. Plug the other end of the charging cable into a charger or computer. During charging, the red LED on the speaker stays ON it turns off when fully charged. Warning The power adapter for charging the product is 5V/1A, if use high voltage power adapter for charging the machine, there is the risk of burning machine! <td> Technical Index Correspond With : V5.4 Support : HSP · HFP · A2DP · AVRCP Transmitting Power : Class 2 Working Distance : ≤10m Frequency Range : 2.402GHz-2.480GHz Charge Time : ≤2.5 Hours Music Time of speaker : ≤15 Hours </td></td></td></td></td>	Connect with two phones 1. Turn off the Bluetooth function on the connected phone, and the speaker will automatically enter pairing mode. Blue and red light flashes alternately 2.Connect with second mobile phone Choose SX133 gets connected 3.Turn on phone 1 Bluetooth and select SX133 gets connected Phone 1 connects <td> Managing Music Music Control Play/Pause Short press previous Long press - button to select previous song next track Long press + button to select next song Increase volume Short press + button to increase volume decrease volume Short press - button to decrease volume Management Calls Answer/ Hang up Short press to answer / end call reject call Long press 1 second Smart voice Double tap to activate Smart Voice. <td> Restore to factory settings If the speaker cannot enter pairing mode or fails to connect, please restore to factory settings. While powered on Press and hold both buttons for 5 seconds. Red and blue lights stay on simultaneously. Wait for the lights to turn off to complete the operation. <td> Charging procedure 1.Open the USB charging port cover. 2.Insert the smaller end of the USB charging cable into the speaker. 3. Plug the other end of the charging cable into a charger or computer. During charging, the red LED on the speaker stays ON it turns off when fully charged. Warning The power adapter for charging the product is 5V/1A, if use high voltage power adapter for charging the machine, there is the risk of burning machine! <td> Technical Index Correspond With : V5.4 Support : HSP · HFP · A2DP · AVRCP Transmitting Power : Class 2 Working Distance : ≤10m Frequency Range : 2.402GHz-2.480GHz Charge Time : ≤2.5 Hours Music Time of speaker : ≤15 Hours </td></td></td></td>	Managing Music Music Control Play/Pause Short press previous Long press - button to select previous song next track Long press + button to select next song Increase volume Short press + button to increase volume decrease volume Short press - button to decrease volume Management Calls Answer/ Hang up Short press to answer / end call reject call Long press 1 second Smart voice Double tap to activate Smart Voice. <td> Restore to factory settings If the speaker cannot enter pairing mode or fails to connect, please restore to factory settings. While powered on Press and hold both buttons for 5 seconds. Red and blue lights stay on simultaneously. Wait for the lights to turn off to complete the operation. <td> Charging procedure 1.Open the USB charging port cover. 2.Insert the smaller end of the USB charging cable into the speaker. 3. Plug the other end of the charging cable into a charger or computer. During charging, the red LED on the speaker stays ON it turns off when fully charged. Warning The power adapter for charging the product is 5V/1A, if use high voltage power adapter for charging the machine, there is the risk of burning machine! <td> Technical Index Correspond With : V5.4 Support : HSP · HFP · A2DP · AVRCP Transmitting Power : Class 2 Working Distance : ≤10m Frequency Range : 2.402GHz-2.480GHz Charge Time : ≤2.5 Hours Music Time of speaker : ≤15 Hours </td></td></td>	Restore to factory settings If the speaker cannot enter pairing mode or fails to connect, please restore to factory settings. While powered on Press and hold both buttons for 5 seconds. Red and blue lights stay on simultaneously. Wait for the lights to turn off to complete the operation. <td> Charging procedure 1.Open the USB charging port cover. 2.Insert the smaller end of the USB charging cable into the speaker. 3. Plug the other end of the charging cable into a charger or computer. During charging, the red LED on the speaker stays ON it turns off when fully charged. Warning The power adapter for charging the product is 5V/1A, if use high voltage power adapter for charging the machine, there is the risk of burning machine! <td> Technical Index Correspond With : V5.4 Support : HSP · HFP · A2DP · AVRCP Transmitting Power : Class 2 Working Distance : ≤10m Frequency Range : 2.402GHz-2.480GHz Charge Time : ≤2.5 Hours Music Time of speaker : ≤15 Hours </td></td>	Charging procedure 1.Open the USB charging port cover. 2.Insert the smaller end of the USB charging cable into the speaker. 3. Plug the other end of the charging cable into a charger or computer. During charging, the red LED on the speaker stays ON it turns off when fully charged. Warning The power adapter for charging the product is 5V/1A, if use high voltage power adapter for charging the machine, there is the risk of burning machine! <td> Technical Index Correspond With : V5.4 Support : HSP · HFP · A2DP · AVRCP Transmitting Power : Class 2 Working Distance : ≤10m Frequency Range : 2.402GHz-2.480GHz Charge Time : ≤2.5 Hours Music Time of speaker : ≤15 Hours </td>	Technical Index Correspond With : V5.4 Support : HSP · HFP · A2DP · AVRCP Transmitting Power : Class 2 Working Distance : ≤10m Frequency Range : 2.402GHz-2.480GHz Charge Time : ≤2.5 Hours Music Time of speaker : ≤15 Hours
---	--	---	---	---	--