蓝牙耳机
Bluetooth Headset

快速入门指南
Quick Guide

SX-815

无线蓝牙耳机的使用

为确保正确和安全地使用本耳机 ，请在使用前详细阅读本指南，并保存好。

使用耳机的应注意下列事项：

应在叠波处长期和错叠电池耳机组式，以避免造成听力。

如听处环境存在潜在电脑，请暂停使用耳机，以确保安全。

点合当的使用音时的音量大小和时间。

不应把音量调得太高，导致当听不到周围的声音，如果出现耳鸣可能自音量调得太高，请将音量调至。

不建议在驾驶时使用耳机听歌。

用卡的软件确定使可！在避免耳机进水，以免导致耳机损坏或者损就下降。

如果使用耳机感觉有明显不适，或有刺痛感等其他不良反应时，应立即停止使用本耳机。

不应将耳机储存或处用于温度低于-15°C(5°F)或高于55°C （131°F）的环境，以免影响耳机寿命。

充电和电池：

给本耳机充电前，请先检查充电线是否为原装。

警告：建议使用原装随配备的充电线给耳机充电，如未使用不配套的充电线可能会造成耳机。

本耳机使用内置式不可拆卸充电电池。请勿尝试从耳机中取出电池，以免损坏耳机。

（1）

1. 充电前，请关闭耳机。
2. 连接充电端后，耳机开始充电，充电时，红灯亮。
3. 耳机充满电，红灯熄灭。

■ 耳机包装清单：

- 耳机1个
- USB充电线1条
- 耳塞套2对
- 说明书1本

音量加 / 下一曲
音量减 / 上一曲
收钮键
指示灯

（2）

开机/关机：

1. 在关机状态下，电源开关拨至 "ON" 位3秒，蓝指双灯亮闪3次，耳机提示 "开机" 开将有效机。

2. 在开机状态下，电源开关拨至 "OFF" 位3秒，耳机提示 "关机" ，此时，耳机关机，红灯亮闪3次，熄灭。

电源开关
麦克风
充电端口
多功能键
收钮键

（3）

蓝牙配对步骤：

1. 请将耳机与手机（或其他可用连接功能器）的距离控制在1米范围内，越近越好。

2. 在关机状态下，电源开关拨至 "ON" 位3秒，蓝指双灯亮闪3次，耳机提示 "开机" ，3秒后会进入配对状态，耳机提示 "进入配对" ，此时红蓝交替闪灯。

3. 打开手机或其他带蓝牙功能设备的蓝牙搜索功能，手机上会显示已找到 "SX-815" 。

4. 选择 "SX-815" （部分手机需输入 "0000" 作为配对密码）耳机会自动与手机连接，蓝灯2次，此时，耳机会听见提示 "已连接" 。

将耳机重新与手机连接

1. 当第一部手机配对成功后，关闭第一部手机蓝牙 ，电源开关拨至 "OFF" 位3秒，耳机关机；

2. 按照与第一步手机相同的步骤与第二部手机配对；

3. 打开第一步手机蓝牙功能，选择SX-815，完成与两部手机的配对。

温馨提示：

1、当已配对过的蓝牙设备处于蓝牙开启状态，并在连接距离内，只需要将SX-815开耳机可以自动回连上次连接的设备（如果不是自动回连，请打开蓝牙设备的蓝牙菜单，点击已连接的 "SX-815" 就可以回连。

2、配对时间超过3分钟，耳机会自动关机；超出连接范围和开连接后3分钟内与每部耳机重新配对可以自动回连上一次连接的设备，

3、同时连接两部手机的情况下，两部手机不能同时播放音乐；需暂停其中一部手机的音乐播放，之后让另一部手机播放音乐。两部手机都可进行蓝牙电话功能，可在伊佩上显示耳机剩余电量。

（4）

感语与提醒/音电量指示电量

插听充电：
当手机与耳机通话时，有来电时，耳机会电提示音并伴随振动，播报来电号码 "134...." 或按 "多功能键" 可接听来电；或用耳机的手机直接听来电。

结束通话：
注在通话时，短按耳机的 "多功能键" 即可挂断通话，或用机的手机直接挂断通话。

拒绝通话：
当有来电来电时，或护公布音示音开时播音振动，此时，双击 "多功能键" 通话将会被拒绝，或用机的手机拒绝通话。

发出重接：
双击 " 多功能键 " 即可拨出手机最后一次拨打的号码。

电话转接：
播放时，可双按 " — " ，在手机与耳机间相互切换通话。

语音拨号：
双按 " ✚ " 听电提示音后说 "打电话给XXX" ，手机就会自动拨出该电话（手机内保存有XXX电话），部分手机不适电。

接1拖2：
当第一个电话正在通话中，第二个电话呼入，如果您电脑听第二个来电，双击 "多功能键" ，就可以结束第一个通话，接听第二个来电。

中英文切换：
同时长按 " MFB " 和长按 " — " 键 中，英文可相互转换。

电量指示：
SX-815每次开机时会播示耳机的剩余电量情况，如 "电量满、电量充足、电量中等、电量低、电量电量及时充电" 。

（5）

播放/暂停

耳机正在音乐播放状态下，单击 "多功能键" 可暂停音乐播放；再次单击 "多功能键" 可恢复音乐播放。

上一曲/音量减：在播放音乐时可加按 " — " ，选择上一首音乐，长按 " — " 声低音量。

下一曲/音量加：在播放音乐时可加按 " ✚ " ，选择下一首音乐，长按 " ✚ " 增加音量。

手机故障指示

当耳机与手机失连接后，或距离十手机约10M外，或耳机电池电量偏低，耳机会每隔一分钟左右自动发出提示音，如果在三分钟内回复有效距离，可自动与手机连接，超过3分钟未回复有效距离，10分钟后自动关机。

恢复出厂设置

关机状态下开电时，长按 "多功能键" ，红蓝灯同开3次，恢复出厂设置。

技术参数

号合蓝牙标准：V4.1	支持：HSP . HFP . A2DP . AVRCP
发现功率：Class 2	连接距离：≤10m
操作频率范围：2.402GHz-2.483GHz	开机时间：≤2.5小时
待机时间：≥170小时	充电时间：≥12小时
音乐时间：≥10小时	USB充电电流：≤5V/1A

警示语

选择手表机充电的电源适配器为5V/1A,如使用过度的电压电源适配器为本机电池可能会损坏。

（6）

（7）

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

（8）

For user's safety, please read this manual before using the headset.

The following matters should be paid attention to when using headset:

Please avoid long-term use of high volume mode, because it will lead to hearing loss caused by noise.

If you are in bad condition of potential danger, please stop using headset, in order to ensure safety.

Users should reasonably control the volume and time when listening to the headset.

The volume should not be too high,otherwise you can't hear the voice around, if volume is too high that may appear tinnitus, please lower down the volume.

Don't listen to the music while driving.

Use dry soft cloth to clean the headset! Should avoid the headset into the water, that will cause headset damage.

If you feel obvious discomfort, stimulation, or other adverse reaction when using the headset, stop using it immediately .

The headset should not be stored or used in temperature below 15°c(5°F) or higher then 55°c(131°F),otherwise will reduce the battery life.

（9）

Charging and Battery:

Before charge this headset with charging cable, please check whether the charge cable is original.

Warning :

Please charge the headsets with original charging cable, it may damage the battery or the headset if you are using improper charging cable. This headset has built-in rechargeable battery, so do not attempt to remove the battery from the headset to avoid damaging it.

1. Before charging, it' s better to turn off the headset.

2. Insert the USB charging cable to earpiece jack, the other end of the USB port into the USB charger or any other devices to start charging. The red light flashing means it is charging.

Volume + / Next
Volume - / Previous
LED Indicator
Earbud Retract Button (R)

（10）

3. The headset needs 2.5 hours for fully charging, the red light goes off when fully charged.

■ Package content:

- Headset 1pcs
- Earbud 2pcs
- USB charging cable 1pcs
- User Manual 1pcs

ON/OFF

1. When the headsets is off, push the power button to "ON" the blue light flashes one time; the headset prompts "power on" with vibration.

2. Push the power button to "OFF", the headset prompts "power off" the red light flashes one time.

Microphone
Multifunctional Button (MFB)
ON/OFF
Charging Port
Earbud Retract Button (L)

（11）

Bluetooth connection steps:

1. Please keep your headset and mobile phone as close as you can, within 1 meter.

2. Press to "Power On" it will prompts "pairing" after 5 seconds, and then Red and blue lights flashing alternately when headset is on and ready for pairing.

3.Turn on "Bluetooth" in setting(your device) and find headset name SX-815.

4. Click SX-815 Bluetooth headset gets connected with your mobile phone automatically. Some may require pass code which is 0000.

Pairing the headset with 2 mobile phones

1. After successfully paired with a mobile phone, close the Bluetooth function of the mobile phone, press power button to "OFF" for 3 seconds, headset will power off.

2. Same procedure to get the 2nd mobile phone paired with the Bluetooth headset.

3. Turn on the Bluetooth function of the 1st mobile phone; choose "SX-815" to finish the pairing status with the 2nd mobile phones.

Note :

1、With you perviously paired device' s Bluetooth turned on and in range , turn on SX-815. The headset will automatically reconnect to the same Bluetooth device that connected last time. If you have a previously paired device that does not auto-recon sect , navigate to the Bluetooth settings menu on your device , turn on the Bluetooth feature , and select "SX-815" from your list of paired Bluetooth devices .

（12）

2、Pairing time exceeds 3 minutes, SX-815 will automatically shut down; in 3 minutes back to the effective distance can automatically return to the last connected device .

3、If connected with two mobile phones, only one mobile phone supports wireless music and you can start conversation for both mobile phones. Battery check up through iPhone.

Answer & End call / Incoming call vibration remind

Answer phone call :

When there is an incoming call, there will be a voice Prompts, 134...578 (phone number will be broadcasted), short press " MFB" button to answer; or just operate your mobile phone.

End Call :

Short the "MFB" button to hang up calls, or by direct hang up your phone call.

Reject call :

When there is an incoming call, headphone will broadcast the phone number with vibration, Double click the "MFB" to reject, or just reject it on your mobile phone.

Last number redial :

Double click "MFB" button.

Call Transfer :

Switch toggle the volume " — " two times to transfer incoming call between phone and headset.

（13）

Voice Dial :

Unlock the mobile phone switch toggle " ✚ " two times to launch the voice dial, and than just speak the people name you want to call, This function can work only if your mobile phone support it.

Hang up the phone call and answer other incoming call

If there is an incoming call when you are answering the phone call, and you want to Answer the other incoming call, double click the "MFB" button, you can hang up the phone call, and answer the incoming call.

Chinese/English Shift :

Long press the "MFB" and switch toggle volume " — " simultaneously for 2 seconds.

Power prompt :

Each time turning on SX-815, it will report headset battery power remaining, such as " battery full" , "battery level high" , "battery level medium" , "battery level low " , "recharge headset " .

Play/Pause

During music playing, Short press "MFB" to pause music, and click again MFB back to play .

During music playing, switch toggle " ✚ / — " one times to change songs.

（14）

During the call or listening to music, user can long switch toggle " ✚ " or " — " button to adjust the volume.

Mobile phone anti-lost indicator

When the headphone connected with smart phone. If the distance between device and headphone out of 10 m, headset will prompts "Beyond the range of connections" . If coming back to the working distance within 3 min or after, the headset will reconnect Automatically with smart phone . If not coming back to the working distance in 10 min, has tohave will be power off, please switch the button to the OFF then switch to ON ,headset will reconnect with smart phone.

Restore Factory Settings

Turn off the headset and in charge state, long press "MFB" button for three seconds, the blue light flashes three times, it will back to factory setting.

■ Technical Index

- Correspond With : V4.1
- Support : HSP . HFP . A2DP . AVRCP
- Transmitting Power : Class 2
- Working Distance : ≤10m
- Frequency Range : 2.402GHz-2.480GHz
- Charging time : ≤2.5 Hours
- Standby Time : ≥170 Hours
- Talk Time : ≥12 Hours
- Music time : ≥10 Hours
- USB power supply : ≤5V/1A

⚠ Warning

The power adapter for charging the product is 5V/1A, if use high voltage power adapter for charging the machine, there is the risk of burning machine!

（15）

Tips:

Wrong way of setting back the wire

Press the Earbud Retract Button directly. In this way, the earbuds will hit the headset aggressively.

Correct way of setting back the wire

In order to prolong the working life of the headset, please setback the wire slowly, and follow the steps shown below.

Hook the wire by your hands.
Press the Earbud Retract Button to let the Earbuds setback in your hands.
Let go of your curved fingers.
Press the Earbud Retract Button to allow the rest of the earbuds to retract inside headset.