



200*60mm 25# 银底UL黑字



Wal-Mart Stores, Inc.
Bentonville, AR 72716
MICROWAVE OVEN
HOUSEHOLD USE ONLY
NOT FOR BUILT-IN INSTALLATION
MODEL: MS8636127995-01
Input: 120VAC, 60Hz,
1350W(Microwave)
1450W(Convection)
Output Power: 900Watts
Microwave Frequency: 2450MHz
FCC ID: UHW90230011
MADE IN CHINA
Manufactured: January 2026
CALL CENTER: 1-866-321-9509



Intertek
3105816
CONFORMS TO UL STD.923

WARNING: TO PROVIDE CONTINUED PROTECTION AGAINST ELECTRIC SHOCK, CONNECT TO PROPERLY GROUNDED OUTLETS ONLY.

THIS UNIT MAY BE EQUIPPED WITH AN INTENTIONALLY UNGROUNDED CONTROL TRANSFORMER. SERVICE PERSONNEL - TO AVOID RISK OF ELECTRIC SHOCK, DO NOT CONTACT CONTROL TRANSFORMER WHILE UNIT IS ENERGIZED. DISCONNECT ELECTRIC POWER BEFORE SERVICING.

A SHORT POWER-SUPPLY CORD IS PROVIDED TO REDUCE THE RISKS RESULTING FROM BECOMING ENTANGLED IN OR TRIPPING OVER A LONGER CORD.

WARNING: RISK OF ELECTRIC SHOCK. NON-REMOVABLE FASTENERS ARE PROVIDED BECAUSE OF HIGH INTERNAL VOLTAGES. DO NOT REMOVE FASTENERS.

CAUTION: THIS DEVICE IS TO BE SERVICED ONLY BY PROPERLY QUALIFIED SERVICE PERSONNEL. CONSULT THE SERVICE MANUAL FOR PROPER SERVICE PROCEDURES TO ASSURE CONTINUED COMPLIANCE WITH THE FEDERAL PERFORMANCE STANDARD FOR MICROWAVE OVENS AND FOR PRECAUTIONS TO BE TAKEN TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY.

PLUG INTO A SEPARATE 15 AMP 120 VOLT AC OUTLET ONLY.

PRECAUTIONS FOR SAFE USE TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY. DO NOT ATTEMPT TO OPERATE THE OVEN WITH:

- OBJECT CAUGHT IN DOOR.
- DOOR THAT DOES NOT CLOSE PROPERLY.
- DAMAGED DOOR, HINGE, LATCH, OR SEALING SURFACE.

THIS OVEN COMPLIES WITH DHHS RADIATION PERFORMANCE STANDARDS, 21CFR SUBCHAPTER J. MICROWAVE FREQUENCY: 2450 MHz

To open the microwave:

1. Press the "0/UNLOCK" or "STOP/CANCEL".
2. Push the door release button.



Optional – To turn off the lock feature:

1. Press the "0/UNLOCK" for 3 seconds.
**The display will indicate "Loc".*
2. Press the "7".
3. Press the "9".
**The display will show "ULoc".*



**Optional – To turn the lock feature back on, repeat the above steps.*