



## 802.11a - Ant 0

## Channel 117 (6535MHz)

## The Reference Level




## The Mask Data




## Channel 157 (6715MHz)

## The Reference Level




## The Mask Data




## Channel 181 (6855MHz)

## The Reference Level




## The Mask Data




## 802.11a - Ant 0

## Channel 185 (6875MHz)

## The Reference Level




## The Mask Data




## Channel 189 (6895MHz)

## The Reference Level




## The Mask Data




## Channel 213 (7015MHz)

## The Reference Level




## The Mask Data




802.11a - Ant 0

Channel 229 (7095MHz)

The Reference Level




The Mask Data




## 802.11ax-HE20 - Ant 0

## Channel 01 (5955MHz)

## The Reference Level




## The Mask Data




## Channel 49 (6195MHz)

## The Reference Level




## The Mask Data




## Channel 93 (6415MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 - Ant 0

## Channel 97 (6435MHz)

## The Reference Level




## The Mask Data




## Channel 105 (6475MHz)

## The Reference Level




## The Mask Data




## Channel 113 (6515MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 - Ant 0

## Channel 117 (6535MHz)

## The Reference Level




## The Mask Data




## Channel 157 (6715MHz)

## The Reference Level




## The Mask Data




## Channel 181 (6855MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 - Ant 0

## Channel 185 (6875MHz)

## The Reference Level




## The Mask Data




## Channel 189 (6895MHz)

## The Reference Level




## The Mask Data




## Channel 213 (7015MHz)

## The Reference Level




## The Mask Data




802.11ax-HE20 - Ant 0

Channel 229 (7095MHz)

The Reference Level




The Mask Data




## 802.11ax-HE40 - Ant 0

## Channel 03 (5965MHz)

## The Reference Level




## The Mask Data




## Channel 51 (6205MHz)

## The Reference Level




## The Mask Data




## Channel 91 (6405MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 - Ant 0

## Channel 99 (6445MHz)

## The Reference Level




## The Mask Data




## Channel 107 (6485MHz)

## The Reference Level




## The Mask Data




## Channel 115 (6525MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 - Ant 0

## Channel 123 (6565MHz)

## The Reference Level




## The Mask Data




## Channel 147 (6685MHz)

## The Reference Level




## The Mask Data




## Channel 179 (6845MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 - Ant 0

## Channel 187 (6885MHz)

## The Reference Level




## The Mask Data




## Channel 195 (6925MHz)

## The Reference Level




## The Mask Data




## Channel 211 (7005MHz)

## The Reference Level




## The Mask Data



## 802.11ax-HE40 - Ant 0

## Channel 227 (7085MHz)

## The Reference Level



## The Mask Data

