

Installation guide

XS4 One S Keypad for European mortise locks




SALTO
inspired^{access}

- (Eng) Installation guide
(E) Guía de instalación
(D) Montageanleitung
(F) Guide d'installation
(I) Guida all'installazione
(P) Guia de instalação

E i 950 xxK series




Only with UL listed
SALTO mortise lock or latch



Mortise Lock not included

Cerradura de embutir no incluida



SALTO recommends the use of a mortise lock, with a maximum 4° pre-turn.

SALTO recommande d'utiliser des serrures à mortaiser avec un angle au repos de 4° maximum.

SALTO recomienda utilizar cerraduras con un pregiro máximo de 4°.

(Eng) * Required only for doors that exceed 60mm [2-3/8"] thickness

(E) * Sólo para puertas de espesor mayor de 60mm [2-3/8"]

"A2" version has to be installed always with the SALTO LT2L tubular latch.
La versión "A2" solo se puede instalar con el picaporte tubular SALTO LT2L.



SALTO LT2Lxx
Tubular Latch

Outside
Exterior

Inside
Interior

**SALTO LT2Lxx
Tubular latch**

With Ei9xxA2.. Only!


To be used only with SALTO compatible escutcheons!

A utiliser uniquement avec les ensembles plaques-béquilles SALTO compatibles!

¡Utilizar solamente con escudos SALTO compatibles!



Ø25
Ø1"




i	t		
	Door thickness		
3	32 - 47mm	35 mm	-
4	45 - 60 mm	50 mm	-
6	60 - 75 mm	30 mm	x2
7	75 - 90 mm	45 mm	x2
9	90 - 105 mm	30 mm	x4
1	105 - 120 mm	45 mm	x4
2		35 mm	-
A	32 - 53 mm	35 mm	-
B		45 mm	-
5		45 mm	-

Installation guide


XS4 One S Keypad for European mortise locks

SALTO
inspired access

(Eng) Select handing (E) Seleccione mano (D) Drückerichtung wählen (C) Choisir le sens de la bêteuille
(I) Scegliere il verso (P) Seleccione mão



(Eng) Installation (E) Instalación (D) Installation (F) Installation (I) Installazione (P) Instalação




Installation guide


XS4 One S Keypad for European mortise locks

SALTO
inspiredaccess


4




5




6




7



8





9



- ⚠**
- AT THIS POINT DO NOT
CLOSE THE DOOR
PROGRAM THE LOCK FIRST**
- NO CIERRE LA PUERTA.
PROGrame LA CERRADURA**
- TÜR NICHT SCHLIESSEN.
ZUERST SCHLOSS
PROGRAMMIEREN**
- NE FERMEZ PAS LA PORTE.
PROGRAMMEZ LA BÉQUILLE
AVANT**
- PROGRAMARE LA SERRATURA
PRIMA DI CHIUDERE LA PORTA**

Eng Battery change
F Remplacer les piles
E Cambio de pilas






Installation guide

XS4 One S Keypad for European mortise locks

SALTO
inspired access

E i 951 xx.. series

E i 9P1 xx.. series



Eng Other models E Otros modelos D Andere Modelle F D'autres modèles I Altri modelli P Outros modelos

E i 956 xx..

- Eng -Entry lock with privacy/ lockout funtion
E -Modelo entrada con privacidad
D -Beschlag mit Privacy-Funktion
F -Béquille électronique avec fonction privacité
I -Modello di entrata con privacy
P -Modelo entrada com privacidade

E i 9P6 xx..

- Eng -Entry lock with privacy/lockout funtion and key override
E -Modelo entrada con privacidad y llave de emergencia con registro
D -Beschlag mit Privacy-Funktion und Notschlüssel
F -Béquille électronique avec fonction privacité et clef de secours
I -Modello di entrata con privacy e chiave di emergenza con registrazione
P -Modelo entrada com privacidade e chave de emergencia com registro

