

'SPRINTER' Bluetooth Sporty In-ear Headphones

- [1] Bluetooth/play/call button
- [2] volume + / next track button
- [3] volume - / previous track button
- [4] Bluetooth LED
- [5] NFC sensor position (optional)
- [6] built-in mic. for speaker phone function
- [7] input recharging port – micro USB
- [8] LED for charge indication
- [9] recharge/charge cord
- [10] accessory changeable in-ear size pads (L/M/S 3-sizes/pairs, M size default affixed)

Product Features

- light & secure wearing neckband design
- built-in magnets stay-well-around-neck convenience
- IPX-4 splash proof for sporty actions
- stereo quality music
- handsfree call pick function
- Bluetooth v3.0 wireless
- NFC pairing option

Charging the headphones

- a) lift up the rubber cover, connect the micro USB port with the charging cable;
- b) plug the charging cable USB end with  marking to an USB port power source;
- c) RED LED lights up, indicates charging;
- d) when speaker is fully charged (approx. 2 hrs), LED will turn off


NFC™ Pairing with your phone

If your smart phone is NFC enabled,

- a) press and hold [play/call]  button 3sec to turn headphones ON;
- b) wait till LED flashing fast (8x/sec.) to show ready for pairing;
- c) locate the NFC antenna spot on your smart phone;
- d) NFC antenna is now on the outside of the headphones' right side housing,
- e) align NFC antennas as close as possible, you will hear a 'cling' sound when they matched,
- f) wait for a few second and you will hear a 'Bloop' sound from the headphones and its blue LED will lit continuously. The pairing is completed now.

Note-

1. "The N-Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries."
2. Some phone models are NFC enabled, but their NFC Apps were not built-in. For these models you will need to install a NFC Apps and activate the NFC function on your phone— Please visit our website to download the driver installer : <http://www.manova.com.hk/download.php>

**Pairing the headphones (manually)- if your phone is NOT NFC enabled**

- a) press and hold [play/call]  button 3sec to turn headphones ON;
- b) wait till LED flashing fast (8x/sec.) to show ready for pairing;
- c) for first time, browse smart phone Bluetooth device list, search and select the one 'SPRINTER';
- d) wait till a beep tone on the headphones which is sent from your phone, and then the blue LED constant lit;
- e) now pairing connection is successful


When you need to disconnect the headphones;

- f) switch off Bluetooth function on your smart phone,
- g) the headphones' blue LED will flash slowly (1x/sec.)
- h) then press and hold [play/call]  button 3sec to turn headphones OFF, (the pairing memory will be kept there)


Next time when you turn ON the headphones again, it will automatically connect to your smart phone again and blue LED lit constant (your smart phone's Bluetooth function also need to be ON and is nearby <5M)

If you need to pair the speaker with a new smart phone;


- i) switch off Bluetooth function on your smart phone,
 - j) then power on your new smart phone's Bluetooth function.
 - k) after press and hold [play/call]  button 1sec to reset, the headphones' blue LED will be flashing fast again (8x/sec.), and
- Then you repeat steps as in above a) to e).

**Wearing the headphones**

1. default in-ear pads are M (mid) size, you may pull out and re-snap in the Large or Small size accessory pad pairs to the earphone tubes, whichever suits you more comfortably,
2. there are built-in magnets holding the headphones as one piece,
3. hold the left side and right side, open/separate the headphones and put neckband over the back of your neck,
4. rest the neckband loop parts hanging over your left and right ears
5. tuck-in the left and right earphones (with pads) against your ear holes that you feel comfortable and secure (fit to the outer opening part of your ear canals)
6. do the other way around step 5>4>3>2 to take off the headphones, or you may snap the headphones together and let them rest around your neck like a necklace, ready to wear again conveniently

**Call-pick function**

When headphones are connected to your smart phone (blue LED lit continuously), whenever there is an incoming call ring, you can press [play/call]  button once on right earphone side to pick up and use the headphones as speaker phone. (press button once again will switch the call to your smart phone)

**How to Use / Controls****Adjust volume**

During music playback or call, press & hold [+/-next]  to increase speaker volume, or [-/previous]  to reduce speaker volume. You have to press and hold until adjust volume to desire level.

Next-forward / Previous-backward

During music playback, press [+/-next]  once will forward to play next track; press [-/previous]  once will backward to previous track. You may press multiple times to forward or backward multiple tracks in a jump.

Play/Pause

During music playback, press [play]  once will pause playback, press again to resume play.

Battery low > recharge

There will be some beeping alert sound during playback. Then charge the headphones as mentioned steps in above section.

Specifications:

dimensions:
product weight:

W 138 x D 45 x H 112 mm (including neckband)
40g

Bluetooth wireless connection
support multiple pairing:

v3.0 +EDR; class II; typ. 8M visible distance; max. 10M
up to 4 devices**

driver:

dia. 13mm x2

driver max. output :

3mW x2

signal to noise ratio:

94db (Audio DAC)

operation voltage

min. 3V; max. 4.2V DC

built-in 3.7V Li-polymer rechargeable battery

battery charging voltage

typ. 5V; max. 5.5V DC (via. USB port)

battery charging current

100mA max. (circuit auto-regulated)

battery charging time

2 hours.

drain current (power on, no input)

<=15mA

playback/standby time

up to 13 hours (fully charged, volume at 1/3 level)

*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

and any use of such marks by Manova International Limited is under license. Other trademarks and trade names are those of their respective owners.

*Design and specifications are subject to change per technical needs, without prior notice

**This speaker supports pairing 'records' up to 4 devices, but NOT 'connection' to 4 devices at the same time

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.