







TX-A001-1



FCC ID: ULZ-TXA001
IC: 30249-TXA001





A1234567



MOORE
SENSOR

SN: 1234567890





TX-A001-2BL



FCC ID:ULZ-TXA001
IC:30249-TXA001





A1234567



MORE
SENSOR
SN:1234567890







TX-A002





FCC ID:ULZ-TXA001
IC:30249-TXA001



A1234567

MORE
SENSOR
SN:1234567890





TX-A003




FCC ID:ULZ-TXA001
IC:30249-TXA001



A1234567



MORE
SENSOR
SN:1234567890



TX-A003-1




FCC ID:ULZ-TXA001
IC:30249-TXA001




A1234567



MORE
SENSOR
SN:1234567890





TX-A003EU-1



FCC ID:ULZ-TXA001

IC:30249-TXA001




A1234567



MORE
SENSOR

SN:1234567890





TX-A004




FCC ID:ULZ-TXA001
IC:30249-TXA001




A1234567



MORE
SENSOR
SN:1234567890






MORE
SENSOR
SN:1234567890

A1234567

TX-A101

FCC ID:ULZ-TXA001
IC:30249-TXA001





TX-A102



FCC ID:ULZ-TXA001
IC:30249-TXA001



MORE
SENSOR
SN:1234567890

A1234567



