



TX-AXXXEU




FCC ID: ULZ-TXA001
IC: 30249 TXA001



A1234567



MORE
SENSOR
SN: 1234567890



AX-SXXX



FCC ID: ULZ-TXA001
IC 30249 TXA001




A1234567



MORE
SENSORS
SN: 1234567890





TX-SXXX




FCC ID: ULZ-TXA001
IC 30249 TXA001



A1234567



MORE
SENSORS
SN: 1234567890



TX-A


FCC ID: ULZ-TXA001
IC: 30249 TXA001



A1234567

MORE
SENSORS
SN: 1234567890





TX-AXXX



FCC ID: ULZ-TXA001
IC 30249 TXA001




A1234567



MORE
SENSORS

SN: 1234567890





TX-K001



FCC ID: ULZ-TXA001
IC 30249 TXA001




A1234567



MORE
SENSOR

SN:1234567890



MORE
SENSOR

SN:1234567890

A1234567



TX-K002



FCC ID:ULZ-TXA001
IC 30249 TXA001

