

Start Here

Welcome to AMG00



OVERVIEW

Please note

All the functions in this manual should be operated in Standby Mode.

Like the picture below.


Tips:

Press **END**



go back to the

Standby Mode



(Standby Mode)

Make a call

Input the numbers, Press **Send** .

Answer a Call.

Press the **Send**. 

Tips:



***down Key** to volume down..

***up Key** to volume up.

*To unlock the keypad **Left Soft**

Key> *



OK>OK



Missed Calls

OK>>OK>1

Display your recent missed numbers.

Dialed Calls

OK>>OK>2

Display your recent dialed numbers.

Received Calls

OK>>OK>3

Display your recent answered numbers.

Delete All

OK>>OK>5

You could delete all the records of the Dialed, Received, Missed and Rejected.

Call timers


OK>>OK>6

Display Last Call, Received Calls, Dialed Calls, and All Calls. Press Left Soft Key to "Reset".

GPRS Counter

OK>>OK>7

Display Last sent, Last received, Total sent, and Total received. Press Left Soft Key to "Reset".



Call logs	
1 Missed calls	0
2 Dialed calls	0
3 Received ...	0
4 Rejected c...	0
5 Delete all	
6 Call timers	
7 GPRS cou...	
OK Back	

Contacts

To browse the name card holder, store, edit and delete the names and phone numbers in the phone and SIM card.

Tips:



To Add:

Options>New

To Edit

Choose the contact>Options>Edit

To Delete

Choose the contact>Options>Delete



Message

To receive and send the message.



Write Message

To write new message.

In box

Store the SMS and Push message

Out box

Store the SMS you've sent in failure.

Drafts

Store the SMS you've edited.

Sent box

Store the SMS you've sent successfully.

Tip: Press # to select the desired input methods

Press * to input symbols

Multimedia

FM Radio

Please connect with the earphone You can listen to Fm radio freely.

Press  key

Tip: For the performance Multimedia function please insert the T-flash card.

up key to volume +.

down key to volume - .



Camera

The device is equipped with a webcam with high pixels. You can take photo at any time.

Press **OK**>>**OK**>**OK**

Press ok to take the picture



Internet

The device is compatible with WAP service. You can visit news, weather forecast and airlines etc.


Press **OK** >  > **OK**

***Depends on network support.**



Calculator

Press **OK** >  > 4 > **OK**





Settings

You can customize the settings, such as time and date, language, call settings etc.

Tips:

Press **OK** >  > **OK**




Ring settings:

OK>  **>OK.**

To customize the ring

Settings options>settings>ring settings.



Thank you!

CAUTION!

“Using the wrong type of battery, there is a danger of explosion.”

“Must be in accordance with the disposal of used batteries.”



For more info:
www.amgoo.com

Empezar Aquí

Bienvenido a AMG00



VISIÓN GENERAL


Por favor, tenga en cuenta

Todas las instrucciones en este manual deben realizarse en modo de espera.

Como en la siguiente imagen.

Consejos:

Presione **END**  y vuelva al modo de espera



(Modo de espera)

Hacer una llamada

Introduzca los números, Presione

Send  .

Contestar una llamada.

Presione **Send**  .



Consejos:

***Tecla abajo** para bajar el volumen.

***Tecla arriba** para subir el volumen.

*Para desbloquear el teclado **Botón**

izquierdo>*



Llamadas



OK>**>Llamadas**

Llamadas pérdidas

OK>**>OK>1**

Mostrar las llamadas perdidas

Llamadas marcadas

OK>**>OK>2**

Mostrar las llamadas marcadas.

Llamadas recibidas

OK>**>OK>3**

Mostrar las llamadas recibidas

Borrar todo

OK>**>OK>5**

Puede borrar todos los registros de llamadas

efectuadas, recibidas, perdidas y rechazadas

Contador de llamadas

OK>  **>OK>6**

Mostrar la última llamada, llamadas recibidas, llamadas efectuadas y todas las llamadas. Presione el botón izquierdo para resetear.

Contador GPRS

OK>  **>OK>7**

Presione arriba y abajo la tecla de navegación para comprobar: Todos los costes, coste máximo, coste medio y resetear coste.

Registros de llamada	
1 madas perdic	0
2 Llamadas ...	0
3 Llamadas ...	0
4 Llamada r...	0
5 Borrar todo	
6 Contadore...	
7 Contador ...	
OK Atrás	

Contactos

Para ver los contactos y números de teléfono, guardarlos, editarlos y borrarlos en el teléfono y en la tarjeta SIM.

Consejos:

Presione **OK** >  > **OK**

Para añadir:

Opciones>Nuevo

Para editar:

Elija el contacto>Opciones>Editar

Para borrar:

Elija el contacto>Opciones>Borrar



Mensaje

Para recibir y enviar el mensaje.

Presione **OK>**



>OK

Escriba el mensaje

Para escribir un nuevo mensaje.

Carpeta de Entrada

Guarda los mensajes recibidos

Carpeta de salida

Guarda los mensajes que se han enviado y han dado error.

Borradores

Guarda los mensajes ha editado.

Carpeta de salida

Guarda los mensajes que se han enviado con éxito.

Sugerencia: Presione # para seleccionar el método de edición de preferencia

Presione * para incluir símbolos

Multimedia

Radio FM

Por favor, conecte con un auricular y podrá escuchar la radio FM gratuitamente.

Presione la tecla



Sugerencia: Para mayor rendimiento de la función multimedia, inserte la tarjeta T-flash.



Tecla Arriba para bajar el volumen +.

Tecla Abajo para subir el volumen -.



Cámara

El teléfono viene equipado con una webcam de muchos píxeles. Puede hacer fotos en cualquier momento.

Presione **OK** >  > **OK** > **OK**

Presione ok para hacer la foto



Internet

El teléfono es compatible con el servicio WAP. Puede ver las noticias, el pronóstico del tiempo, aerolíneas, etc.


Presione **OK** >  > **OK**

***Depende de la red.**



Calculadora

Presione **OK** >  > 4 > **OK**



Configuración

Puede personalizar la configuración, como el día y la hora, el idioma, la configuración de las llamadas, etc.

Consejos:

Presione **OK** >  > **OK**



Configuración del timbre

Tonos>Elegir el perfil.

Para personalizar

opción>ajustes>configuración de tono.



¡Gracias!

PRECAUCION!

**"No utilizar baterías de otro tipo puede
provocar una explosión"**

**"Debe ser de acuerdo con la disposición
de las baterías usadas"**



Para mas informacion:
www.amgoo.com

Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.5CM from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.