



Dispho®

Integrated Tripod



Quick Start Guide


Product description



- 1 Holder handle
- 2 Rotary holder
- 3 Turnover axis
- 4 Aluminum pull rod
- 5 Remote Controller Indicator
- 6 Photo key
- 7 Tripod

1

Bluetooth connection




- 1 If you use an Android phone, before taking photos, ensure that the volume button of your phone is set to the shutter button in camera settings.
- 2 Press the Photo Key for 3 seconds to turn on, Open Bluetooth of mobile phone to enter search state and click "Dispho" in equipment searched; after connection is finished, Green light long on


2

Usage method

- 1 Mount your phone onto the selfie stick




- 2 Extend the monopod




3

- 3 Press the shutter button to take a picture




- 4 How to use holder

Use vertical or horizontal screen by rotating mobile phone for 90 degrees by hands




4

- 5 Press the fill light button (optional)
Open the bottom tripod, uplift the pull rod and put tripod on horizontal plane.



Charging

Take the remote control out, turn the remote control to the reverse side, and remove its back cover according to the arrow direction, then the battery can be replaced.



5

Powering off

Remote controller: Long press photograph key for 3 s, green lamp will flicker for 3 times and then be off, which means machine is shut down.

Tips:

- 1. Selfie stick will enter sleep mode automatically if it is idled for 10 min after Bluetooth connection; press photograph key to recover connection.
- 2. The selfie stick will be shut down automatically if it is idled for 30 min after entering sleep mode.
- 3. When using the Remote control, when the battery is low, the Remote control will have a flashing red light for reminder. Please replace the battery in time.

6

FCC statements:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction.

Model Name: WS-19009

Winners' Sun Plastic & Electronics (Shenzhen) Co., Ltd.
Building E, Yingtai Industrial Zone, Longhua New District,
Shenzhen, China

尺寸: 60*100mm
材质: 80g书纸