





## WA9906 -RFID MODULE LF-ID1 INSTALLATION INSTRUCTION

### 1. Serial number codification




### 2. Label for RFID Module LF-ID1




### 3. Label for 7528 terminal


- a. WWAN European variant:




- b. WWAN American variant:



- c. WIFI variant:




**Label dimensions:**



**1. Installation procedure**

1. Label area for RFID Module LD-ID1 label



2. Label area for RFID Module LF-ID1 label into 7528 terminal:

Label is located under battery.

