




Label Location (inside the battery compartment)
Label is visible to the users as they install the battery