

Title: QSG
Size:(150x150mm)
Printing:Black(double side printing)
Material: 70g W/F paper
Date:06-13-2017

SOUNDFREQ®

Quick Start Guide

Sound Rise Classic


The Sound Rise Classic Bluetooth Alarm Clock Speaker has high quality sound and many features for your enjoyment.

Just follow the simple steps below to check it out.



Bluetooth Playback

1. Press Bluetooth Pair Button to enter pairing mode to pair your device first. (The blue indicator will be fast flashing.)
2. On your device, select "Sound Rise Classic" to connect.
3. Most devices will not require password, if request the default is "1234".
4. Either use the **Play Control** buttons on the unit or your device to control playback and volume.

Notes: To pair another device, press and hold Bluetooth Pair Button for 3 seconds. (The blue indicator will be fast flashing again to pair new device.)




②③ Sound Rise Classic




AUX-IN Playback

1. Press **POWER** button to power on the unit. (The white indicator will be on.)
2. Press **SOURCE** button to select AUX-IN. (The green indicator will be on.)
3. Connect your device to the **AUX IN Cable** on the back.
4. Control playback on your device.
5. Press **Volume** button on the unit or your device to adjust the playback volume.



③ AUX IN Cable



Charging Your Mobile Device


Simply connect your device to the USB ports on the top for charging.

Notes: The maximum charging output is 5V/2.1A.

Setting the Alarm

1. Rotate **ALARM SET** knob on the side in the direction of arrow till your desired alarm wake-up time is shown.
2. Slide **ALARM** switch to **ON** position to turn the alarm on.
3. Slide **WAKE TO** switch to your desired wake up mode (**BT/AUX/BEEP**).
 - If wake to **BT (Bluetooth)**, please make sure to pair your device first and set the playback volume loud on your device for waking up.
 - If wake to **AUX**, please make sure your device is playing and set the playback volume loud on your device for waking up.
4. Press **POWER** to switch off the unit and goodnight. (Do not adjust the volume level on your device and the unit after setting.)


Notes: Do not set the volume too low on your device for alarm wakeup purpose.



Turning off the Alarm


1. Press **SNOOZE / LIGHT** button while alarm is sounding. The alarm sound is temporarily paused and starts again after 10 minutes later. You can repeat up to 12 times.
2. Slide and keep the **ALARM** switch to **OFF** position to shut off the alarm before leaving the room.

Notes: Slide the **ALARM** switch back to **ON** before your bedtime at night.



Using UQ3 Sound Enhancement

Press the **UQ3** button to switch on the sound enhancement for great enjoyment of your music.



Title: Instruction Manual
Size:(150x150mm)
Printing:Black(double side printing)
Material: 70g W/F paper
Date:06-15-2017


SOUNDFREAK®

Instruction Manual


Sound Rise Classic

Using and Setting the Alarm

- 1 Turn the alarm setting knob in the direction of arrow on the side of the unit to adjust the alarm pointers to your desired wake-up alarm time.




- 2 Slide the **ALARM** switch on top of the unit to **ON** position to turn the alarm on.



- 3 Slide the **WAKE TO** switch to select alarm sound among BT/AUX/BEEP modes.

- 4 **Wake to BT: (3 simple steps to set up your mobile device as the alarm music source)**

- I **PAIR and SELECT SONG:** Press the **PAIR** button to pair your device. Then, select your favorite wake-up song to play.



- II **SET ALARM VOLUME:** Press volume "+/-" button to the desired volume level to wake up.
You may also need to adjust the volume level on your device for higher volume.

- III **READY:** Once done, simply press **POWER** button to turn off the unit and goodnight. (Do not adjust the volume level on your device and the unit after setting.)

Wake to AUX: (3 simple steps to set up your mobile device as the alarm music source)

- I **PLUG-IN and SELECT SONG:** Press the **POWER** button to turn on the unit and press **SOURCE** button to select AUX. Plug the **AUX-IN Cable** on the back into your mobile device and select your favorite wake-up song to play.

- II **SET ALARM VOLUME:** Press volume "+/-" button on the clock radio to the desirable volume to wake up.
You may also need to adjust the volume on your device for higher volume.

- III **READY:** Once done, simply press **POWER** button to turn off the clock radio and goodnight. (Do not adjust the volume level on your device and the unit after setting.)

Notes:

- When waking up to Bluetooth or AUX, Sound Rise Classic will "play" the current song on your connected/plugged in device. If no audio signal is detected when the alarm goes off, Sound Rise Classic will wake you with its built-in chime after a while.
- Do not set the volume too low on your device for alarm wakeup purpose.


Using Snooze and Shutting off the Alarm

- 1 If you prefer to get some more sleep after the alarm goes off, simply press **SNOOZE / LIGHT** button while the alarm is sounding.

The alarm sound will go off .

The alarm will sound again after 10 minutes.

(The snooze function will repeat 12 (Max.) times.)




Notes:

When alarm is sounding or snooze is in operation, all the control buttons on the unit will be temporarily disabled till alarm switch is slid to **OFF** to avoid interruption of alarm operation.

- 2 If you want to shut the alarm off completely, simply slide the **ALARM** switch to **OFF** position to turn off the alarm before leaving the room.


- Notes:** Slide the **ALARM** switch back to **ON** before your bedtime at night.



Listening with Bluetooth

Bluetooth Pairing

- 1 We need to pair your mobile device with the unit before using the Bluetooth.
- Simply press the **PAIR** button directly, the unit will turn on automatically and start pairing mode. The blue indicator will flash rapidly.
- If the unit has been paired before, the blue indicator will flash slowly a few times then pairing your devices automatically.
- 2 On your device, open your Bluetooth setting menu to detect available devices. Once Sound Rise Classic is detected, select it from the list of available devices to connect. On most devices, no password is needed to pair, however, if a password is requested, the default password is "1234".




Sound Rise Classic



Notes: To pair another new device, simply press and hold the **PAIR** button for 3 seconds to disconnect currently paired device. The Bluetooth indicator will flash rapidly again and select "Sound Rise Classic" on your new device.


Playing Music via Bluetooth

- 1 After pairing, either use the Play Control buttons on the Sound Rise Classic or your device to control playback.
- 2 You can change the volume by either using the **Volume** buttons on the Sound Rise Classic or adjusting the volume on your paired device. For max volume, turn both volumes to maximum.



Listening with AUX-IN

- 1 Connect any device with a standard (3.5mm) headphone jack using the **AUX-IN Cable** attached on the back of the Sound Rise Classic.
- 2 Turn on the unit and then press the **SOURCE** button until the green indicator stays on to enter the AUX IN mode.




AUX IN Cable

Charging your Mobile Devices


You can charge most USB chargeable devices directly from the Sound Rise Classic. Simply connect your device to either USB ports on the top of Sound Rise Classic to begin charging.

Notes: The maximum charging output is 5V/2.1A.



Using the Backlight


Simply, press the **SNOOZE / LIGHT** button to momentarily turn the backlight on for 5 seconds to see the time.



SNOOZE / LIGHT

Using UQ3 Sound Enhancement

Press the **UQ3** button to turn on/off the UQ3 effect for great enjoyment of your music. The power indicator will flash once when UQ3 is turned on and flash twice when UQ3 is switched off.



UQ3

Power Indicator

Title:Installation Instructions

Size:(150x150mm)

Printing:Black(double side printing)

Material: 100g W/F paper

Date:06-15-2017

SOUNDFREAQ[®]

Installation Instructions for Hotel Staff


Sound Rise Classic

System Hardware Setup


The Hotel version of Sound Rise Classic includes a bracket to ensure the DC power jack cannot be removed.

For additional security, it also includes a lanyard to allow tethering of the Sound Rise Classic to furniture if required. See instructions below for fitting.


- 1** Insert the DC plug of the supplied power adaptor into the DC IN jack on the back of the unit.




- 2** Place the bracket onto the DC plug. Insert the tabs of the bracket into the slots of the system (A), and push the bracket up to lock it in place (B).




- 3** Align the screw hole on the bracket and the unit, and tighten the screw to fix the bracket to the unit.



- 4** Fix the end of the lanyard to a secure and firm place using the supplied screw. (Or other screw if applicable for fixing on different places.)



- 5** Unscrew and open the battery door and then insert the battery into the battery compartment, tighten the screw on battery door.



- 6** Leave the quick start guide in the guest room with the Sound Rise Classic.

SOUNDFREAQ®



Installation Instructions for Hotel Staff

Sound Rise Classic

Setting the Time

For the first time setup , please set the time of the clock.

Rotate the TIME SET knob in the direction of arrow on the back of the unit to adjust the pointers to the desired time by using a Philips screw driver.




System Reset

Turn on the unit, then press and hold **SNOOZE / LIGHT** and **PLAY** button simultaneously for 5 seconds to reset the unit to the default settings for a new hotel guest, and the unit will be powered off (Once reset, both of the indicators will flash once and then switch off.)

Notes:

After resetting the unit , the Bluetooth connection and the previous user settings (volume setting) will also be reset to the default setting.



Battery Replacement

Caution: To avoid battery leakage, please make sure to replace battery when the battery is low.

There is a backup battery for keeping the clock time for power outage. When the level of backup battery is low, the power indicator will flash. It is the time to replace the battery.