



Quick Setup Guide
A30 Smart Payment Terminal


PAX Technology Limited

1. Checklist


Congratulations on receiving your PAX Technology payment terminal. We do hope you enjoy it! The box you have just opened should contain the following items:

- 1 x PAX A30 Smart Payment Terminal
- 1 x USB Cable
- 1 x Quick Setup Guide
- 1 x AC Power Cable (Optional)
- 1 x AC Power Adapter (Optional)

2. Product Description



3. Installation



- **USB Port:** connect to a USB-enabled device.
- **SAM/microSD Cards:**

The A30 has one SAM card slot on the main body of the device and one microSD card slot. These card slots are normally hidden under the back cover. In order to install a microSD or SAM card into any of these slots, insert a card into the card slot with the contacts facing upwards and the clipped corner of the card facing forward and to the right.

- Unscrew the back cover.
- Push the cover to the right.
- Insert SAM /microSD card into the appropriate card slot and replace cover.

4. Instructions

- **Power On/Off:** Power On: Plug the terminal into an electric outlet; the terminal will power on automatically.
Power Off: press and hold the Power button for 3 seconds until the shutdown menu appears, tap Power Off > Click Power Off, and “Shutting Down” will appear.
- **Contactless Transactions:** Tap a contactless enabled card or smartphone in proximity to the top of the terminal where the contactless sensor is located, indicated by the contactless icon.
- **Chip Card Transactions:** With the card's chip facing upwards, insert the chip card fully into the chip card slot.
- **Magnetic Stripe Transactions:** With the card's magnetic stripe facing downwards, swipe the card through the magnetic reader at a constant speed, in either direction.

5. General Usage Tips

- Avoid placing this product in direct sunlight for extended periods, nor in environments with excessively high temperature, moisture or dust.
- Only qualified personnel should repair this product.
- Before using cards in the chip & magstripe readers, please ensure they are free from any foreign objects.

6. Important Safety Warning

- Do not place the terminal or battery in direct sunlight, nor in environments with excessively high temperatures, smoke, dust, or dampness.
- We recommend you only use power adaptors supplied by PAX Technology. If you must use 3rd party supplier accessories, please ensure specifications meet exactly those recommended for our products, which must comply with international and local regulations & standards. Non-compatible power supplies, chargers or batteries could cause fires or even explosions, and will invalidate any product warranty.
- When disposing of the device, battery, or accessories, please do so responsibly and according to local regulations. These are not household waste items. Improper disposal of the battery could cause a fire or explosion, and any liquid leakage could be damaging to the environment and toxic to humans & animals.

7. Environmental Parameters

- **Working Environment:**
Temperature: -10°C~50°C (14°F~122°F)
- **Storage Environment:**
Temperature: -20°C~70°C (-4°F~158°F) (non-charging)
- **Humidity:**5%~95% (non-condensing)

8. Icons



Dispose in a professional recycling manner



microSD logo

Trademark notice:

microSD logo is a trademark of SD-3C LLC.

9. FCC Regulations:

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

10. FCC RF Exposure Information (SAR)

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 7.9 inches between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

11. Quick Setup Guide

PAX reserves the right to change product specifications & material components at any time

Scan here for latest version



PAX continually invests to maintain its high quality products up to date with the latest certifications, therefore a comprehensive list can be requested via the website's contact form or on downloadable product brochures.

Built by:	PAX Computer Technology (Shenzhen) Co. Ltd.
Address:	Room 701, PAX Technology Building, Shanxia Community, Pinghu Sub-district, Longgang District, Shenzhen, China
Tel:	+86 755 86169630
Website:	www.pax.com.cn

FCC Supplier's Declaration of Conformity

Smart Payment Terminal / A30

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party: PAX Technology, Inc.

8880 Freedom Crossing Trail, Building 400, 3rd Floor Suite 300, Jacksonville, Florida, 32256

Help-desk

1 877-859-0099