




LED indicator	Status	Description
	Solid on	<ul style="list-style-type: none">The router is starting.The router is faulty after start-up.
	Blinking	The system is working properly.
	Solid on	The LAN port is connected properly.
	Blinking	Data is being transmitted over the LAN port.
	Off	The LAN port is disconnected or connected improperly.
	Solid on	The WAN port is connected properly.
	Blinking	Data is transmitting over the WAN port.
	Off	The WAN port is disconnected or connected improperly.
	Solid on	At least the 2.4 GHz or 5 GHz Wi-Fi network is enabled.
	Fast blinking	Data is transmitting wirelessly.
	Slow blinking	The router is performing WPS negotiation.
	Off	The WPS function of the router is disabled.
	Solid on	A USB device is connected to the USB port properly.
	Blinking	Data is transmitting over the USB port.
	Off	The USB port is disconnected or connected improperly.



设计: 丁瑞丰

校对：

批准：

日期：