




BATTERY CAUTION:

1. Rechargeable batteries are not recommended.
2. Alkaline batteries are recommended.
3. Non-rechargeable batteries are not to be recharged.
4. Rechargeable batteries are to be removed from the toy before being charged.
5. Rechargeable batteries are only to be charged under adult supervision.
6. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
7. Do not mix old and new batteries.
8. Only batteries of the same or equivalent types as recommended are to be used.
9. Batteries are to be inserted with the correct polarity.
10. The supply terminals are not to be short-circuited.
11. If batteries are loose, bend out the contacts for a tight fit.
12. Exhausted batteries must be removed from the toy and be disposed of immediately.
Do not put the batteries in a fire.
13. Remove batteries from the toy when not in use.
14. Check the product periodically for signs of damage to electrical parts;
do not play with product until damage has been properly assessed.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

TOYOTA
OFFICIAL
LICENSED
PRODUCT

TOYOTA, TACOMA and all other associated marks, emblems and designs are intellectual property rights of Toyota Motor Corporation and used with permission by Grandex International Development Ltd.



Don't put in trash.
Recycle or dispose
as hazardous waste.

Alkaline batteries are recommended.
Batteries should be installed by adults only.

Please keep this packaging for future reference.
Colors, designs & contents may vary.
All rubber bands, plastic and wire ties, as well as tags, are not
part of this toy and should be discarded for your child's safety.
Remove wire ties before giving this toy to your child.

49MHz

409998-15313-001-041526
DISTRIBUTED BY
GREENBRIER INTERNATIONAL, INC.
500 VOLVO PARKWAY,
CHESAPEAKE, VA 23320
MADE IN CHINA



1 95464 71678 6