



## **WARNING!**

This product was created to kill mice by electrocution. It emits a high voltage shock. **DO NOT** allow children to play with or be anywhere near this device. Any small animals entering this device when the power is on, may be killed.

People with heart conditions should take special care when handling this device. Do not use near flammable liquids, vapors or other combustibles because of danger of explosion or fire. Turn off power when handling. Keep hands and all objects out of the chamber unless the device is turned off and batteries are removed.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation..

### **Setting the Trap:**

1. Bait the Mouser.
2. Place the Mouser in the desired location – rodents usually scurry around walls and other corners.
3. Flip On/Off button to the ON position- the LED will blink three times in ON state and one more

time indicating the Mouser is Armed.

4. When the Mouser is Tripped, the LED will blink once every three seconds and the user will be notified via a notification on the Dome App. A notification is resent every 24 hours to remind the user that the Mouser needs to be emptied.

5. Flip the On/Off button to the OFF position to empty the Mouser, and it is ready to use again immediately.

Product Name : WiFi Mouser

Model: WFMZ1

FCCID:VII-WFMZ1

IC:22838-WFMZ1



WFMZ1

Label Location:

