

Find thousands more
great ideas online

Brookstone®

870796 870797 870798

Merrimack, New Hampshire, USA 03054 • 800-846-3000 • Brookstone.com



Brookstone®

BIG BLUE LIVE²

WIRELESS SPEAKER



870796 (Black), 870797(White), 870798 (Red)
Size:4"Wx4"H_Output:100%_Prints:1/1,Blk

TABLE OF CONTENTS

Warnings and Cautions.....	1
FCC Information.....	5
RSS Information.....	7
Location of Parts and Controls.....	8
Travel Lock.....	9
Charging the Speaker.....	9
Pairing Your Device.....	10
Pairing Your Device with NFC.....	11
Listening to Audio.....	12
Using the Speakerphone.....	13
Using Pair2 for Stereo or Left/Right Sound.....	14
Using Aux In.....	16
Care and Maintenance.....	16
Specifications.....	17
Troubleshooting.....	18
Warranty.....	20

Warranty does not apply to any non-Big Blue Audio products. Manufacturers or suppliers other than Big Blue Audio may provide their own warranties to the purchaser, but Big Blue Audio, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Big Blue Audio; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BIG BLUE AUDIO SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BIG BLUE AUDIO DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BIG BLUE AUDIO CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

ONE (1) YEAR LIMITED WARRANTY

Big Blue Audio LLC warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Big Blue Audio will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Big Blue Audio, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Big Blue Audio's property. When a store credit is given, the original product must be returned to Big Blue Audio and becomes Big Blue Audio's property.

Obtaining Service: To obtain warranty service, call Big Blue Audio Limited Warranty Service at 866-577-8955. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Big Blue Audio that can be identified by the "Big Blue Audio" trademark, trade name, or logo affixed to them or their packaging. The Limited

CAUTION

- TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER.
THERE ARE NO SERVICEABLE PARTS INSIDE.
- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.



The lightning flash with arrow-head symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the unit's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.

IMPORTANT SAFETY INSTRUCTIONS

All of the safety and operating instructions should be read, adhered to and followed before the unit is operated.

SAFETY AND HANDLING INFORMATION

For maximum product life, do not drop, throw, or crush the speaker. Do not expose it to humidity, dust, or operating temperatures outside 32°F to 113°F (0°C to 45°C).

SAVE THESE INSTRUCTIONS

DANGER

To reduce the risk of electric shock, burns, fire or injury:

1. Do not use while bathing or in a shower.
2. Do not place or store unit where it can fall or be pulled into a tub or sink.
3. Do not place in, drop or submerge in water or other liquid.
4. Do not reach for a unit that has fallen into water. Unplug it immediately.
5. Care should be taken so that objects do not fall and liquids are not spilled onto the unit.

TROUBLESHOOTING (CONTINUED)

ISSUE	SOLUTION
Can not pair with NFC.	Confirm your device has NFC capability by referring to your device's owners manual.
Can not put speakers in Pair2 stereo or left/right mode.	Confirm your device is paired to the first speaker. Please refer to page 10 for pairing instructions. Confirm there is not a previous device paired to the second speaker. Confirm both the first and second speaker are in Pair2 connection mode. Please refer to page 14 for Pair2 connection instructions.
Buttons will not activate.	Confirm TRAVEL LOCK SWITCH is on  .

TROUBLESHOOTING

ISSUE	SOLUTION
Bluetooth® disconnection.	Ensure your device is within 33 feet of the speaker and reconnect your device to "Big Blue Live 2.0."
Audio is not clear.	Power the speaker off and then back on.
	Adjust your device's equalizer.
	Check the speaker or your device's volume level.
Speaker does not play audio.	Make sure the speaker is charged
	Power the speaker off and then back on.
	Confirm device is paired.
	Note: The speaker remembers the last device paired. If you would like to use another device, pair that device manually. Please refer to page 10 for pairing instructions.

LITHIUM-ION BATTERY WARNINGS

This device contains a non-removable Lithium-Ion battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.

WARNING

1. Close supervision is necessary when this appliance/product is used by or near children or mentally disabled individuals.
2. Use this unit only for its intended use as described in this manual.
3. Unplug this unit during lightning storms or when unused for long periods of time.
4. Never drop or insert an object into any opening.
5. Protect the power cord from being walked on or pinched, particularly at plug outlets, convenience receptacles and the point where it exits the unit.
6. Do not allow cord to touch hot surfaces. Wrap cord loosely

around the unit when storing.

7. The unit should be situated away from direct sunlight or heat sources such as radiators, electric heaters, heat registers, stoves, or other units (including amplifiers) that produce heat. Avoid placing on top of stereo equipment that radiates heat.
8. Never block the air openings of the unit with materials such as clothing, plastic bags or papers, or place it on a soft surface such as a bed or couch, where the air openings may be blocked.
9. Do not overload the electrical outlet. Use only the power source as indicated.
10. Do not carry this unit by its cord or use the cord as a handle.
11. Never operate this unit if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water. If the unit's power supply cord or plug is damaged, do not attempt to fix it yourself.
12. To avoid the risk of electric shock, do not disassemble or attempt to repair the unit. Incorrect repair can cause risk of

SPECIFICATIONS

Power Supply (input)	AC 100V~240V, 50/60 Hz
Power Supply (output)	DC 5V, 1000mA
Power Output	9W
Range	Class 2, up to 33 ft (10 m)
Speaker	1.7", 8 Ohm (x2)
Compatibility	Bluetooth 3.0 or above with A2DP/AVRCP/HFP/HSP
Li-ion Rechargeable Battery	2100 mAh
Battery Life	Approx. 6 hours
Charging Time	Approx. 4.5 hours
Weight	Approx. .8lbs
Dimensions	5.5" (w) x 2.75" (d) x 2.6" (h)

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Brookstone is under license.

© Brookstone 2015

USING AUX IN

1. Plug one end of the included 3.5mm-to-3.5mm cable into your audio device, just like you would a pair of headphones.
2. Plug the other end of the cable into the unit's AUX IN port.
3. Use your audio device to control music playback.
4. Use your audio device and the speaker to control volume.

Note: If a device is currently paired with Bluetooth®, the wired device takes precedence over a Bluetooth device connection.

CARE AND MAINTENANCE

Wipe the speaker with a soft, dry cloth.

electric shock or injury to persons when the unit is used.

13. Do not operate in the presence of explosive and/or flammable fumes.
14. Never remove the plug from the outlet by pulling the power cord.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician

each speaker, and the speakers will be in stereo mode.

7. Press the PLAY/PAUSE/PHONE BUTTON on either speaker to resume audio.
8. To put the speakers in left/right mode, press and hold the Pair2 BUTTON on the **first speaker** or the **second speaker** until the Pair2 left and right tones sound on each speaker.
9. To put the speakers back into stereo mode, press and hold the Pair2 BUTTON on the **first speaker** or the **second speaker** until the Pair2 stereo tones sound on each speaker.
10. To exit out of Pair2 stereo or left/right modes, power either speaker off by pressing the POWER BUTTON.

USING Pair2 FOR STEREO OR LEFT/RIGHT SOUND

Two Big Blue Live² speakers can be paired for stereo or left/right sound.

1. Pair your device (see page 10) with the **first speaker**.
2. Press and hold the POWER BUTTON on the **second speaker** until the POWER/PAIRING LED turns on and the power on tone sounds.
3. Press the Pair2 BUTTON on the **first speaker** (the speaker that is paired with your device).
The POWER/PAIRING LED will start flashing and audio will pause on the **first speaker**. The **first speaker** will wait for a Pair2 connection for up to 2 minutes.
4. Press and hold the Pair2 BUTTON on the **second speaker** until the POWER/PAIRING LED starts flashing on the **second speaker**.
5. Release the Pair2 BUTTON on the **second speaker**.
6. After a few seconds, the POWER/PAIRING LEDS will be solid, the Pair2 stereo tone will sound on

for help.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

Modifications not authorized by the manufacturer may void the user's authority to operate this device.

FCC ID: VL5-BBLIVEV2

LOCATION OF PARTS AND CONTROLS

1. Power Button
2. NFC Sensor
3. Volume -
4. Play/Pause/Phone Button
5. Power/Pairing LED
6. Volume +
7. Charging LED
8. Aux In Port
9. Micro USB Port
10. Travel Lock Switch
11. Pair2™ Button
12. AC/DC Adapter
13. Micro USB Cable



USING THE SPEAKERPHONE

When the speaker is paired to your device and a call is received, the incoming call tone will sound.

If there is audio playing though the speaker when a call is answered, the audio will pause and only your call will be audible. When you end the call, your audio will resume.

- To answer an incoming call press the PLAY/PAUSE/PHONE BUTTON.
- To reject an incoming call press and hold the PLAY/PAUSE/PHONE BUTTON.
- To end an active call press the PLAY/PAUSE/PHONE BUTTON.
- To switch an active call from the speaker to your device press and hold the PLAY/PAUSE/PHONE BUTTON.
- To switch an active call from your device to the speaker press and hold the PLAY/PAUSE/PHONE BUTTON.

LISTENING TO AUDIO

1. Press and hold the POWER BUTTON until the POWER/PAIRING LED turns on and the power on tone sounds.
2. The speaker should automatically remember the last paired device. Depending upon your device, you may have to select "Big Blue Live 2.0" in your device's menu.
3. Press the VOLUME + BUTTON to increase audio volume.
4. Press the VOLUME - BUTTON to decrease audio volume.
5. Press the PLAY/PAUSE/PHONE BUTTON to pause audio. Press the PLAY/PAUSE/PHONE BUTTON to play audio.
6. To turn the speaker off, press the POWER BUTTON. The power off tone will sound.

Note: If no buttons are pressed, the POWER/PAIRING LED will auto off after 5 seconds. Pressing the VOLUME or PLAY/PAUSE/PHONE BUTTON buttons will activate the POWER/PAIRING LED for 5 seconds.

TRAVEL LOCK

1. Slide the TRAVEL LOCK SWITCH to  to lock the buttons on the speaker.
2. Slide the TRAVEL LOCK SWITCH to  to unlock the buttons on the speaker.

Note: Sliding the TRAVEL LOCK SWITCH to  will power off the speaker.

CHARGING THE SPEAKER

1. Insert the MICRO USB CABLE'S micro USB connector into the MICRO USB PORT on the speaker.
2. Insert the MICRO USB CABLE'S USB connector into the USB port on the AC/DC ADAPTER.
3. Plug the AC/DC ADAPTER into an electrical wall outlet.
4. The CHARGING LED INDICATOR is RED while the speaker is charging. When the speaker is fully charged, the CHARGING LED INDICATOR is GREEN. For first time use, charge the speaker for at least 4.5 hours.
5. When the speaker's battery is low, the CHARGING LED INDICATOR will flash RED.

PAIRING YOUR DEVICE

1. Prepare your device to pair using Bluetooth®, making sure the device is within 33 feet of the speaker. Refer to your device's owners manual for details if necessary.
2. Press and hold the POWER BUTTON until the POWER/PAIRING LED turns on and the power on tone sounds.
3. Press and hold the POWER BUTTON until the POWER/PAIRING LED starts flashing to put the speaker in pairing mode.
4. Select "Big Blue Live 2.0" on your device. If prompted, use 0000 as a PIN for the pairing code. The speaker will wait for a connection in pairing mode for up to 2 minutes.
5. When "Big Blue Live 2.0" is selected, the POWER/PAIRING LED will be solid blue and the pairing successful tone will sound to confirm pairing is complete.

Notes:

- To cancel the pairing mode you may either press the POWER BUTTON, a tone will sound and the speaker will turn off, or wait the 2 minutes for the speaker to cancel

pairing automatically. The POWER/PAIRING LED will return to solid blue and the unit will remain on.

- The POWER/PAIRING LED will auto off 5 seconds after pairing. Pressing the VOLUME or PLAY/PAUSE/PHONE BUTTON buttons will activate the POWER/PAIRING LED for 5 seconds.

PAIRING YOUR DEVICE WITH NFC

1. Enable your device for NFC pairing. Refer to your device's owners manual for details if necessary.
2. Touch your device to the speaker's NFC SENSOR. Confirm the connection on your device.