





REMARKS:


1. Emission Level = Read Level+ Antenna Factor + Cable Loss- Preamp Factor
2. Margin value = Limit value- Emission level.
3. 5775MHz: Fundamental frequency.

Test Report No.: RF260714B015




ANTENNA POLARITY & TEST DISTANCE: VERTICAL AT 3 M

Rg	Frequency [MHz]	PK+ Level [dBμV/m]	PK+ Limit [dBμV/m]	PK+ Margin [dB]	Correction [dB]	Polarization	Azimuth [deg]	Antenna Height [m]
11	5,623.750	59.83	68.20	8.37	44.53	V	1	1.00
12	5,751.250	106.25			44.62	V	269.6	1.00
13	5,983.500	59.89	68.20	8.31	44.35	V	359.1	1.00




REMARKS:

- Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
- Margin value = Limit value- Emission level.
- 5745MHz: Fundamental frequency.




ANTENNA POLARITY & TEST DISTANCE: VERTICAL AT 3 M


Rg	Frequency [MHz]	PK+ Level [dBμV/m]	PK+ Limit [dBμV/m]	PK+ Margin [dB]	Correction [dB]	Polarization	Azimuth [deg]	Antenna Height [m]
11	5,602.188	59.56	68.20	8.64	44.58	V	356.7	1.00
12	5,787.813	105.46			44.75	V	88	1.00
13	5,971.125	59.04	68.20	9.16	44.29	V	187.2	2.00



REMARKS:

- Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
- Margin value = Limit value- Emission level.
- 5785MHz: Fundamental frequency.







REMARKS:

1. Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
2. Margin value = Limit value- Emission level.
3. 5825MHz: Fundamental frequency.


Test Report No.: RF260714B015






REMARKS:


4. Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
5. Margin value = Limit value- Emission level.
6. 5745MHz: Fundamental frequency.






REMARKS:


- Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
- Margin value = Limit value- Emission level.
- 5785MHz: Fundamental frequency.






REMARKS:


- Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
- Margin value = Limit value- Emission level.
- 5825MHz: Fundamental frequency.






REMARKS:


7. Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
8. Margin value = Limit value- Emission level.
9. 5745MHz: Fundamental frequency.






REMARKS:


7. Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
8. Margin value = Limit value- Emission level.
9. 5785MHz: Fundamental frequency.






REMARKS:


7. Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
8. Margin value = Limit value- Emission level.
9. 5825MHz: Fundamental frequency.






REMARKS:


10. Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
11. Margin value = Limit value- Emission level.
12. 5745MHz: Fundamental frequency.






REMARKS:

10. Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
11. Margin value = Limit value- Emission level.
12. 5785MHz: Fundamental frequency.





REMARKS:

10. Emission Level = Read Level+ Antenna FAXtor + Cable Loss- Preamp FAXtor
11. Margin value = Limit value- Emission level.
12. 5825MHz: Fundamental frequency.