



APPENDIX II SETUP PHOTOS

RADIATED EMISSION SETUP

Test Mode: Normal Operation





Test Mode: POE Mode





RADIATED RF MEASUREMENT SETUP





ANTENNA PORT CONDUCTED RF MEASUREMENT SETUP





CONDUCTED EMISSION SETUP

Test Mode: Normal Operation





Test Mode: POE Mode

