



RW-TH68N


Thank you for purchasing a Rosewill Bluetooth Headphones.  
Please read the instruction manual before use and retain for future reference.

## CAUTION

- Please charge the battery if you can not turn on the headphones
- Please turn off the headphones after use to maintain a longer battery life
- Please use USB cable included in the package for battery charging
- Please do not change any other battery
- Please do not keep headphones in a wet environment
- Do not exposure or toss headphones into fire
- Please do not try to disassemble the headphones

## PRODUCT OVERVIEW

1. Next track/Volume up
2. Previous track/Volume down
3. MFB button
4. USB charging port
5. Bluetooth indicator
6. Noise cancelling button
7. Noise cancelling indicator
8. 3.5 mm jack



## INSTRUCTIONS

---

### Battery Charging

- Battery: Rechargeable Polymer Lithium-Ion Battery (DC: 3.7V/290 mAh).
- Power: Please use the USB DC5V cable included in the package for charging.
- Charging Time: When charging for the first time, please be sure the battery is charged more than 4 hours to be fully charged. After the first time, charging time is about 3 hours.
- When the red light is on, the headphones are in charge mode. The red light will turn off when the battery is fully charged.

### Noise Cancellation Function

When you slide the NC button to the ON (the red mark) side, the indicator will turn on, then you can enjoy the headphones in Noise Cancellation mode. When you do not need the Noise Cancellation function, slide the NC button to the OFF side.

### Pairing Headphones with Bluetooth Devices

- Turn the headphones on by holding down the MFB button until you hear the voice say "ON". To turn off, hold down the same button until you hear the voice say "OFF".
- Please keep the headphones and mobile phone in the range of 1 meter when pairing and make sure your headphones are off.
- Press and hold the MFB button for 5 seconds to put the headphones in pairing mode (if successful the LED light will flash red and blue).
- Go into the Bluetooth settings on your device, search for new Bluetooth devices and select RW-TH68N.
- The LED light will blink blue when the headphones are successfully paired.

Notes: If the pairing is not successful, please turn the headphones off and on, then try to pair again.

## Making Calls with the Headphones

| FUNCTION                                                  | STATUS            | OPERATION                                                                                                                                                                                                                     |
|-----------------------------------------------------------|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Redial Last number                                        | Standby mode      | Quickly short press MFB twice                                                                                                                                                                                                 |
| Volume up                                                 | Conversation mode | Short press Volume + button                                                                                                                                                                                                   |
| Volume down                                               | Conversation mode | Short press Volume - button                                                                                                                                                                                                   |
| Answer call                                               | Ringing           | Short press MFB button                                                                                                                                                                                                        |
| Reject call                                               | Ringing           | Press and hold MFB button for one second, then release when you hear indication sound                                                                                                                                         |
| Transfer the call between headphones and Bluetooth device | Conversation mode | Press and hold the MFB button for 3 seconds to transfer the conversation from headphones to mobile phone. Then press and hold the MFB button for 3 seconds to transfer the conversation back from mobile phone to headphones. |

### Notes:

- Not all mobile phones support every function listed above. Please refer to the instructions of your mobile phone.
- Some functions and indication tones may vary with mobile phones.

## Playing Music

When the headphones connect with the mobile phone or Bluetooth transmitter, you can enjoy music through headphones wirelessly.

| FUNCTION       | STATUS        | OPERATION                   |
|----------------|---------------|-----------------------------|
| Pause          | Playing music | Short press MFB button      |
| Play           | Pausing       | Short press MFB button      |
| Next track     | Playing music | Short press Volume + button |
| Previous track | Playing music | Short press Volume - button |
| Volume up      | Playing music | Long press Volume + button  |
| Volume down    | Playing music | Long press Volume - button  |

## SPECIFICATIONS

---

Bluetooth Solution: CSR 8635

Bluetooth Version: V5.0

Support Agreement: A2DP, AVRCP, HFP, HSP

Operating Distance: 10 m

Battery: 290 mAh

Charging Time: about 3 hrs

Charging Current: 170 mA

Music Playing Time: 16 hrs (50% volume)

Talking Time: 18 hrs (50% volume)

Driver Unit: 40 mm

Sensitivity: 105 dB/1 mW (SPL at 1 kHz)

Impedance: 32Ω

Frequency Range: 20 Hz-20 kHz

## FCC WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.  
The device can be used in portable exposure condition without restriction.



Technical Support Information: [techsupport@rosewill.com](mailto:techsupport@rosewill.com) 1-800-575-9885  
Please register your product at [www.rosewill.com](http://www.rosewill.com) for complete warranty information and support for your product.



RW-TH68N\_A