

Make sure the TV is laid face-down on a flat surface. Remove the original screws in the bracket holes on the TV back. (For 55")

Place the spacers (not provided) in the holes of the purchased bracket (1.5mm to 2.5mm thickness) on the TV with 4 screws

With rounded screws

Remote Control and Stand are optional depending on customer's requirement

- (2) To simplify multiple TV set installation, enter configuring a TV, all its settings may be cloned (copied) to additional TV units via USB; to begin:
- (1) Connect a fully configured TV unit via USB to AC Power;
- (2) Plug a USB drive into USB port on the side of the TV;
- (3) Press the **POWER** key on the remote control;
- (4) Press the **USB** connection, are you sure you want to switch to USB?;
- (5) Press **MENU**;
- (6) Select "SOUND" sub-menu and press **ENTER**;
- (7) Select "BALANCE" and press **ENTER**;
- (8) Use the Arrow keys on the remote control to adjust balance to zero then enter access code "5 8" using the numeric keys on the remote control to

- For example, to move the channel in position 8 to position 1.
- (a) Highlight the channel in position 8 and press the **RIGHT** arrow key on the remote control.
- (b) Use the **UP** arrow key on the remote control to move the cursor to the channel in position 8.
- (c) The channel that was in position 8 will now be in position 1 and any channels affected by the insertion will automatically be shifted accordingly in the channel map.
- (d) Press the **EXIT** key on the remote control when finished making changes to the channel map. The hotel menu will automatically close.