

FIGURE 1
LED LCD TV (M/N: 50H7EG)
COVER REMOVED



FIGURE 2
LED LCD TV (M/N: 50H7EG)
LCD PANEL LABEL



FIGURE 3
LED LCD TV (M/N: 50H7EG)
POWER BOARD (COMPONENT SIDE)




FIGURE 4
LED LCD TV (M/N: 50H7EG)
POWER BOARD (SOLDERED SIDE)




FIGURE 5
LED LCD TV (M/N: 50H7EG)
MAIN BOARD (COMPONENT SIDE)



FIGURE 6
LED LCD TV (M/N: 50H7EG)
MAIN BOARD (SOLDERED SIDE)




FIGURE 7
LED LCD TV(M/N: 50H7EG)
CHIP #1 & CRYSTAL #1 ON MAIN BOARD




FIGURE 8
LED LCD TV (M/N: 50H7EG)
CHIP #2 & CRYSTAL #2 ON MAIN BOARD




FIGURE 9
LED LCD TV (M/N: 50H7EG)
TUNER ON MAIN BOARD



FIGURE 10
LED LCD TV (M/N: 50H7EG)
CRYSTAL OF TUNER ON MAIN BOARD




FIGURE 11
LED LCD TV (M/N: 50H7EG)
KEY BOARD (COMPONENT SIDE)




FIGURE 12
LED LCD TV (M/N: 50H7EG)
KEY BOARD (SOLDERED SIDE)




FIGURE 13
LED LCD TV (M/N: 50H7EG)
RF BOARD #1 (COMPONENT SIDE)



FIGURE 14
LED LCD TV (M/N: 50H7EG)
RF BOARD #1 (SOLDERED SIDE)



FIGURE 15
LED LCD TV (M/N: 50H7EG)
RF BOARD #2 (COMPONENT SIDE)



FIGURE 16
LED LCD TV (M/N: 50H7EG)
RF BOARD #2 (SOLDERED SIDE)




FIGURE 17
LED LCD TV (M/N: 50H7EG)
LCD PANEL CONTROL BOARD (COMPONENT SIDE)



FIGURE 18
LED LCD TV (M/N: 50H7EG)
LCD PANEL CONTROL BOARD (SOLDERED SIDE)



FIGURE 19
LED LCD TV (M/N: 50H7EG)
DEBUG #1




FIGURE 20
LED LCD TV (M/N: 50H7EG)
DEBUG #2

