




USER MANUAL



Avantree VoxAmp Lite

Model No.: BTVA-01

01 Things To Note

EN

- ◆ Please read the instructions first.
- ◆ Please follow the instructions carefully.
- ◆ Please store and use this product at room temperature.
- ◆ Do not use this product near heat sources such as radiators, heat registers, stoves, or other apparatuses (including amplifiers) that produce heat.
- ◆ Do not block the opening of the speaker, and do not insert objects into the vents or slots of the speaker.
- ◆ Do not throw or drop the product to avoid damage.
- ◆ Please charge the speaker with the product-rated voltage.
- ◆ If the connection line does not match your device, please contact the dealer.
- ◆ Please keep the speaker volume at a moderate level to avoid temporary or permanent hearing impairment.
- ◆ If the equipment is damaged for any reason, it must be repaired by professional maintenance personnel in a timely manner. Unauthorized disassembly will invalidate the warranty.
- ◆ If the battery is not properly replaced, there may be a risk of explosion. It must only be replaced with the same type of battery.
- ◆ Do not disassemble, impact, squeeze, or throw the battery into fire. If severe swelling occurs, stop using it immediately. Do not place it in a high-temperature environment, and do not use it after the battery has been soaked in water.
- ◆ The battery (battery pack or combined battery) must not be exposed to conditions such as direct sunlight, fire, or other overheating environments.
- ◆ If consumers use a power adapter to charge, they should use a certified power adapter that has obtained CCC certification and meets standard requirements.

Q&A

The Amplifier has no voice?


1. Please check if the amplifier has power or if the power switch is turned on.
2. Please check the audio source and the cable connection.
3. Please check if the audio signal output from the source is normal.
4. Please check if the volume of the amplifier or the audio source has been turned down to the minimum.
5. Please have a try to restart the amplifier.

What to do if the amplifier howling?

1. Please try appropriately reduce the volume a little.
2. Please maintain an appropriate distance between the microphone and the amplifier.

03 Packing List

EN




1.Amplifier



2.Microphone



3.Strap



4.USB Type-C cable



5.User manual

04 Keys Functions

EN

LED Indicator

Bluetooth mode:

- Fast Blinking: Waiting for pairing;
- Solid On: Connection successful.

USB mode: Solid on.

Recording mode: Slow blinking.


Charging: Red light solid on while charging, red light off when fully charged.

Power button: Long press for 2 seconds to turn on or off.

M Button

Mode Switching: Short press to switch between Bluetooth mode > Amplifier mode > USB mode (if a USB drive is inserted).
Note: Default mode is Bluetooth mode upon power on.

Disconnecting Bluetooth: Long press the M button. Reconnecting Bluetooth: Press the play button briefly again



Local Recording: Insert a USB drive while the device is powered on. Long press the "▶" to start recording, while LED indicator slow blinking. Long press the "▶" again to exit recording mode.

Playback of Recordings: While the device is powered on, double click the "▶" to enter playback mode for recorded files. Short press the M button to exit playback. Note: Playback of recordings defaults to folder loop mode, only loop play the recorded folder files.

Delete Recordings: During playback of a recorded file, long press the "▶" to delete the currently playing file.

Play Button: Short press to play/pause.

Short Press: Increase volume.
Long Press: Skip to the next track.

05 Ports Functions

EN




USB Drive Playback:

Insert a USB drive while the speaker is powered on, the speaker will automatically play the music files stored on the USB drive.

Power Charging:

Connect to a DC 5V - 1A USB power adapter for charging.



Wired Microphone Port:

Connect a 3.5mm wired microphone to use.

06 Bluetooth Connection

EN

1. Turn on the Amplifier:

Long press the power button to turn on the amplifier accompanying a startup prompt sound. The LED indicator fast blinks, indicating waiting for Bluetooth pairing.


2. Connect to a Mobile Device:

Turn on the Bluetooth function on your mobile device. Find K2 in the Bluetooth devices list, connect to it. There is a prompt tone indicating successful connection, and the LED indicator light will remain solid.

After initial pairing, the speaker will auto-connect when powered on and Bluetooth enable on your device.

Disconnecting Bluetooth:

Long press the M button to disconnect from the current device. It will enter pairing mode, waiting for a new connection.



07 Specification

Amplifier parameters

Driver: 3 inch full range speaker unit

Frequency Response: 400-18kHz (-10dB)

Charging: DC5V 1A USB Type-C

Output: 5W

Playback support: USB disk drive, Bluetooth


Other function: Recording and playback

Amplifying: 3.5mm wired microphone

Supported formats: MP3, WMA, WAV, FLAC, APE(USB disk)

Product size: 98.2*38.5*105mm

Product weight: 193g



Troubleshooting

Avantree VoxAmp Lite

Model No.: BTVA-01

FCC ID: WJ5-BTVA01

Made in China



FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.