



Harmony A1

LE Audio Auracast Speaker



Interactive User Guide

Version 1.9

Start Setup

< Back



Main Menu

1. Before You Start
2. Buttons & Indicators
3. How to Charge
4. Use Classic Bluetooth
5. Use Auracast Broadcast

Next




1. Before You Start

- Harmony A1 Solo is a Bluetooth LE Audio speaker that supports Auracast broadcasting.
- Work independently or link with the Harmony A1 system for synchronized, low-latency multi-room audio.

[Next](#)



2. Buttons & Indicators



A LED

- **Orange** (solid) → **Auracast** connected
- **Blue** (solid) → **Bluetooth** connected
- Blinking → Not connected

① MODE Button – Mode Switch

- Double-press M = Switch **Auracast** / **Bluetooth**

② EQ Button – Sound Mode

- Press EQ = Switch Balance/Voice Clear/Bass

Next





3. How to Charge

- Charge via USB-C (5V, 2A)
- **Red** LED on = Charging;
Off = Fully charged (~4 hrs).
- Playtime: Up to 8 hrs (varies by volume).
- Auto power-off: Shuts down if no audio is detected for **60 min** after being connected.
- Can operate while charging for continuous use.

Next



4. Use Classic Bluetooth

4.1 Switch to Bluetooth Mode

- ❶ Turn on speaker → Auracast mode (LED blinks **orange**).
- ❷ Double-press **MODE** → Bluetooth mode (LED blinks **red** & **blue**).

[Next](#)

< Back




Menu

4.2 Connect to Phone

On your phone, turn on Bluetooth, and select "Avantree Harmony A1".

✓ LED stays **solid blue** = **Connected**



Next





5. Use Auracast Broadcast

The speaker works with any Auracast broadcast source (e.g. [Avantree Harmony AI](#), and all Avantree Auracast transmitters, such as [Avantree Oasis Aura](#)).



FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.