

EUT Internal Photos

Figure 3
Internal View (Removed Antenna)



Figure 4
Internal View (Removed Cover)



Figure 5
Internal View



Figure 6
Internal View



Figure 7
Internal View



Figure 8
Internal View




Figure 9
Internal View (Main Board, Front View)



Figure 10
Internal View (Main Board, Back View)




Figure 11
Internal View (RF Board, Front View)



Figure 12
Internal View (RF Board, Back View)



Figure 13
Internal View (RF Board, Removed Cover, Front View)



Figure 14
Internal View (RF Board, Removed Cover, Back View)



*Figure 15
Internal View (Internal Board, Front View)*



*Figure 16
Internal View (Internal Board, Back View)*




Figure 17
AC Adapter (Front and Side View)



Figure 18
AC Adapter (Back and Side View)



Figure 19
AC Adapter (Label View)



Figure 20
RS-232 Cable

