




Test Configuration Photos


Test positions for Head:

Cheek device with left head phantom	Tilt device with left head phantom
	
EUT Setup Configuration C-1	EUT Setup Configuration C-2
Cheek device with right head phantom	Tilt device with right head phantom
	
EUT Setup Configuration C-3	EUT Setup Configuration C-4

Test positions for body:

According to the antenna position, the Body SAR is tested at the following 6 test positions all with the distance =10mm between the EUT and the phantom bottom:

Front in body position (Closed)	Back in body position (Closed)
	
EUT Setup Configuration C-1	EUT Setup Configuration C-2
Left Side in body position (Closed)	Right Side in body position (Closed)
	
EUT Setup Configuration C-3	EUT Setup Configuration C-4
Top Side in body position (Closed)	Bottom Side in body position (Closed)
	
EUT Setup Configuration C-5	EUT Setup Configuration C-6

Bottom Side in body position (Open)	Back in body position (Open)
	
EUT Setup Configuration C-7	EUT Setup Configuration C-8
Left Side in body position (Open)	Right Side in body position (Open)
	
EUT Setup Configuration C-9	EUT Setup Configuration C-10