

FRONT



MODEL: 2IHSK1002

VENTURE

WIRELESS PORTABLE SPEAKER

Product Specifications

Bluetooth Version: V5.4
Power Output: 3W
Input: DC 5V, 1A
Driver Size: 52mm
Battery Capacity: 3.7V, 800mAh
Transmission Distance: 10 meters (approx. 33 feet)

Button Functions & Interfaces

1.

Power ON/OFF - Press and hold for 3 sec. to power on/off. Press to toggle from TF Mode to Bluetooth Mode.

2.

TWS Mode - Double press to turn TWS mode on/off

3.

Volume Up / Next Track - Short press for Next track, long press for volume up.

4.

Volume Down / Previous Track - Short press for Previous track, long press for volume down.

5.


Light Control

6.

TF Card Slot

7.

USB-C Charging Port



1

2

3

4

5

6

7

Charging Instructions

Connect the small plug of the supplied USB charging cable into the DC 5V (Type-C) port on the unit. Connect the standard USB plug into a power source, such as a USB wall charger, PC, or Mac.

Bluetooth Connection

Press and hold the Power button for approximately 3 seconds. An audible tone will play, the blue light will remain steady, and the speaker will enter standby search mode.

Open the Bluetooth settings on your phone or other device and search for the device name "iHome Venture Speaker"

Select the device to connect. A prompt sound will indicate a successful connection. (Pairing typically takes about 1 minute. If a password is required, enter "0000" and confirm).

Note: The pairing process may vary slightly depending on your specific device.

After the initial manual connection, the speaker will automatically reconnect to the last paired device when powered on.

Once connected, the Bluetooth icon will appear on your phone's display.

Note: If the speaker moves out of range, it will disconnect. It will automatically reconnect once it is back within the effective Bluetooth range.

TF Card Mode

While the speaker is on, insert a TF card. The device will automatically switch to TF card mode, a prompt will sound, and music will begin playing automatically after 7 seconds.

Note: This speaker supports MP3 audio formats.

TWS (True Wireless Stereo) Mode

Turn on two speakers. Double-click the button on either speaker to enter TWS mode. That speaker will then act as the main unit.

Light Modes

While powered on, the speaker features multiple light modes.

Light Indicator

Charging: A red light will turn on during charging and turn off once the battery is fully charged.

Safety Precautions

BACK



- Do not expose this product to rain or moisture.
- Do not disassemble, repair, or modify the product yourself.
- Store and use this product in a room-temperature environment.
- Avoid dropping the product to prevent damage.
- Use the rated voltage for charging.
- Avoid listening at maximum volume for extended periods to prevent hearing damage.
- Battery Safety: There is a risk of explosion if the battery is replaced incorrectly. Replace only with the same or equivalent type. Do not expose the battery to excessive heat, such as sunlight or fire.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

According to §15.247(e)(i) and §1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.

According to KDB 447498 (2)(a)(i)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device..

Package Contents:

(1) Speaker, (1) Charging Cable, (1) User Manual

*USB Charger not included.






WARNING: Cancer and Reproductive Harm
- www.P65Warnings.ca.gov

Q support: 877-543-3540

2026 © Lifeworks Technology Group LLC. New York, NY 10018. iHome is a registered trademark of SDI Technologies Inc., used under license. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Lifeworks Technology Group LLC. is under license. All other brands are registered trademarks of their respective companies. USB Type-C™ and USB-C™ are trademarks of USB Implementers Forum. Made in China



Double sided pritning

Accordian Style Booklet