

FRONT





Magnetic Speaker

2IHSK1009-BLK-G7

Product Specifications

Version: 5.3
Play distance: 10M
Charge time: 3~4 Hours
Output power: 5W*2 Material: ABS+Mesh Fabric
Speaker: 52MM 40 5W*2
Sensibility: 75DB Battery: 1200MAH Frequency: 150HZ-18KHZ
Work time: 2 hours
Charging port: TYPE-C Function: BT/MIC/TWS/TF/FM
Size: 81*190mm

Button Functions & Interfaces

1.


Volume Down Button

2.

Power Button

3.

Volume Up Button



Power Button:

Press and hold the power button for 2-3 seconds to turn on the device.

Bluetooth Mode:

After turning on the device, you can play music once connected to Bluetooth.

Short press the "-" button to switch to the previous song. Short press the "+" button to switch to the next song.

Press and hold the "-" button to decrease the volume.

Press and hold the "+" button to increase the volume.

TF Mode:

After turning on the device, insert a TF card to play music automatically.

Short press the "-" button to switch to the previous song.

Short press the "+" button to switch to the next song.

Press and hold the "-" button to decrease the volume.

Press and hold the "+" button to increase the volume.

FM Mode:

After turning on the device, insert a USB cable as an antenna. Then, short press the power button to search for stations automatically. Short press again to stop searching for stations.

Mode Switch:

Double-click the "+" button to switch among BT/TF/FM modes.

LED Mode Switch:

Double-click the "-" button to switch LED modes. The last LED flashing mode is to turn off the LED.TWS Pairing: After turning on two devices, double-click the power button of either device to automatically pair TWS.

Safety Precautions

•

Use Approved Power: Charge only with the included Type-C cable and a certified 5V/1A power adapter to prevent battery damage.

•

Avoid Extreme Heat: Keep the speaker away from prolonged direct sunlight, radiators, and open flames to avoid battery

BACK



hazards.

•

Keep It Dry: Do not expose the speaker to rain, moisture, or high-humidity environments to prevent electric shock.

•

Protect Your Hearing: Avoid listening at high volume levels for extended periods to prevent potential hearing damage.

•

No Disassembly: Do not attempt to open, repair, or modify the device; doing so voids the warranty and risks injury.

•

Handle with Care: Avoid dropping or subjecting the speaker to severe physical impact to protect internal components.

•

Keep Away from Children: Keep the speaker and its small accessories out of reach of young children, as they may present a choking hazard.

•

Safe Cleaning: Clean the exterior only with a soft, dry cloth; do not use harsh chemicals or liquid solvents.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

According to §15.247(e)(i) and §1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner

that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.

According to KDB 447498 (2)(a)(i)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device..

Package Contents:

(1) Speaker, (1) Charging Cable, (1) User Manual

*USB Charger not included.





WARNING: Cancer and Reproductive Harm

- www.P65Warnings.ca.gov



support: 877-543-3540

2026 © Lifeworks Technology Group LLC. New York, NY 10018. iHome is a registered trademark of SDI Technologies Inc., used under license. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Lifeworks Technology Group LLC. is under license. All other brands are registered trademarks of their respective companies. USB Type-C™ and USB-C™ are trademarks of USB Implementers Forum. Made in China

Double sided pritning

Accordion Style Booklet