

FRONT



MODEL: 2IHSK1015

LUX


WIRELESS CHARGING SPEAKER

Product Specifications

Material: ABS + Fabric
Bluetooth Version: V5.3
Wireless Charging: 5W / 7.5W / 15W
Output Power: 10W (5W x 2)
Input Voltage: DC 5V/3A, 9V/3A
Driver: 57mm x 2 Speaker
Speaker Impedance: 4Ω
FM Frequency: 87.5-108MHz
Battery Capacity: 3.7V 1200mAh
Play Time: 3-6 hours (at 50% volume)
Charging Time: 2.5-3 hours
Working Distance: 10 meters
Functions: Bluetooth, TF Card, USB, FM, AUX, TWS

Button Functions & Interfaces

- Wireless Charging Pad
- Short / long press to reduce the volume.
- Short / long press to add the volume.
- Short press the last song.
- Short press the next song.
- Long press function switch BT / White noise / FM mode. Short press play or pause musics. Short press FM station scan in FM mode. Short press answer or hang up the incoming call. Double press to dial the last call.



1

2 3 4 5 6 7 8

7. Short press the timing 15/30/60, Long press for TWS pairing.

8. Long press to turn on / off. Short press light effects switch. Double press to quickly turn on / off the lights.

Charging Instructions

To use the wireless charging feature: You must use a USB-C PD Wall Charger (not included) that is rated for at least 20W. For best results, use a charger labeled "PD" (Power Delivery) with a wattage of 30W, 40W, 45W, or 65W. Plug 1 end of the provided USB C cable to the speaker and plug the other end to a USB-C PD Wall Charger (not included) to enable wireless charging

Power On / Off

To turn on: Press and hold the power button for two seconds. The speaker will power on and activate the default lighting.

Bluetooth (Wireless) Connection

The speaker defaults to Bluetooth mode when turned on and supports A2DP-enabled devices. A voice prompt will indicate when the speaker is in pairing mode and waiting for a connection. Open the Bluetooth settings on your mobile phone and search for available devices. Select iHome Lux Speaker from the list to begin pairing. Once successfully paired, a voice prompt will sound, and your device will show as connected.

True Wireless Stereo (TWS)

Pairing (Note: This function is only available in Bluetooth mode.) If you have two iHome Lux Speakers, you can link them together for a true stereo surround sound experience. Long-press the pairing button on either speaker to connect them to each other. Once connected, the two speakers will automatically separate into left and right audio channels.

Lighting Controls

The iHome Lux Speaker features multiple lighting effects. It defaults to a warm light setting when powered on. Press the Light button to cycle through and adjust the different lighting effects.

Hands-Free Calling

Answer / End a Call: Short press the designated button to answer an incoming call. Short press it again to hang up. Redial: Double press the button to automatically dial the last called number.

FM Radio Mode

Long press the Mode button to switch to the FM Radio function. Important: Plug the Type-C charging cable into the speaker's port to act as a radio antenna (the USB end does not need to be plugged into a power source). Press the Pause/Play button to automatically scan and save available radio stations. Short press the Forward / Backward (+/-) buttons to skip through your saved channels.

BACK



TF Card / USB Drive Mode

Simply insert a TF (MicroSD) card or USB drive into the corresponding slot. A voice prompt will confirm the connection, and the speaker will automatically begin playing the audio files. Use the Forward / Backward (+/-) buttons to skip tracks.

White Noise Mode

Long press the Mode button to switch to White Noise mode. Press the Forward / Backward (+/-) buttons to select your favorite sleep sounds.

Safety Precautions

- The equipment complies with the standard GB 4943.1-2022.
- This product is not a toy; keep it out of the reach of children to prevent accidents.
- Do not place the machine in high-temperature environments, including direct sunlight, fire sources, or heaters. Do not use in humid or rainy environments.
- In addition to the provided charging cable, please do not use other methods to charge the machine.
- Do not disassemble the machine; prohibit any attempt to repair or modify the machine.
- Avoid dropping, impacting, scratching, or behaviors that

affect the function of the machine.

- If the battery is improperly replaced, there is a risk of burning or explosion; replace only with the same type or equivalent type of battery.
- Using the audio at high volume for a long time may cause damage to your hearing.
- If there is any damage, water ingress, high-temperature deformation, abnormal sound/heat, or peculiar smells, stop using the machine immediately and contact the merchant

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

According to §15.247(e)(1) and §1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.

According to KDB 447498 (2)(a)(i)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation,

Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device..

For WPT mode

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Package Contents:

(1) Speaker, (1) Charging Cable, (1) User Manual


*USB Charger not included.



 **WARNING:** Cancer and Reproductive Harm
- www.P65Warnings.ca.gov

 **support: 877-543-3540**

2026 © Lifeworks Technology Group LLC. New York, NY 10018. iHome is a registered trademark of SDI Technologies Inc., used under license. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Lifeworks Technology Group LLC. is under license. All other brands are registered trademarks of their respective companies. USB Type-C™ and USB-C™ are trademarks of USB Implementers Forum. Made in China



Double sided pritning

Accordion Style Booklet