

FRONT




MODEL: 2IHSK1016-BLK-G7
4-IN-1 Speaker

Product Specifications

Bluetooth Version: V5.4
Speaker: 5W x 1
Working Distance: 10 Meters
Wireless Input: DC 5V/3A, 9V/3A
Wireless Charging for Phone: 15W (Max) / 7.5W
Wireless Charging for Apple Watch: 2.5W (Max)
Wireless Charging for Earbuds: 3W (Max)
Battery Capacity: 3.7V / 1800mAh Lithium battery
Charging Input: DC 5V/1A
Charging Time: Approximately 3 hours
Working Time: Approximately 4-5 hours
Product Size: 95 x 95 x 145 mm
Frequency Response: 100Hz -18kHz

Button Functions & Interfaces

- Magnetic Phone Charging
- Earbuds Wireless Charging
- Apple Watch Wireless Charging
- Light
- Short Press: Light ON/OFF, Long Press: Brightness Control
- Short Press: Volume Up, Long Press: Next Song
- Short Press: Pause/Play, Long Press: ON/OFF
- Short Press: Volume Down, Long Press: Previous Song



Connection and Charging

Bluetooth Pairing
Press and hold the "▶" button to power on the speaker. Turn on your smartphone's Bluetooth and search for available devices. Locate the device named "iHome Omni Speaker" in your Bluetooth list. Tap the name on your smartphone to connect. A tone will sound to indicate a successful connection. The speaker will connect to your smartphone automatically the next time it is turned on. *To clear Bluetooth history and restore factory setting press the "▶" button quickly 5 times.

Charging the Speaker
Connect the USB-A end of the provided charging cable to a 30W adapter (not included), and the USB-C end to the wireless charger. Plug the power adapter into a wall socket and turn it on. After successfully connecting to the power supply, the LED lights will flash three times and turn off, indicating that wireless charging is now ready.

Charging Your iPhone
When the wireless charger is ready, correctly place your compatible phone in the center of the Wireless charging pad. Charging will begin, and the LED ambient light will slowly pulse. Verify that your phone is charging successfully. If the LED ambient light flashes quickly, there is a charging error. Try repositioning the phone or removing the phone case.

You must use a USB-C PD Wall Charger (not included) that is rated for at least 20W.

For best results, use a charger labeled "PD" (Power Delivery) with a wattage of 30W, 40W, 45W, or 65W.

Plug 1 end of the provided USB C cable to the speaker and plug the other end to a USB-C PD Wall Charger (not included) to enable wireless charging

Charging Your Wireless Earbuds
When the wireless charger is ready, correctly place your compatible earbuds charging case in the center of Area B. Charging will begin, and the LED ambient light will slowly pulse. If the LED ambient light flashes quickly, there is a charging error. Try repositioning your earbuds case or removing its silicone cover.

Charging Your Apple Watch
When the wireless charger is ready, place your watch in the center of Area C. Charging will begin, though the LED indicator on the base will not light up. The charging icon should appear directly on

Compatible Devices

Phone	iPhone 12, 13, 14, 15, 16 ,17 and newer models.
TWS Earphones	Apple AirPods 2, AirPods and newer models.
Watch	Apple Watch Series 1-9 and newer models.

BACK



your Apple Watch screen. Charging the Speaker Base. Before using the speaker for the first time, charge it for 24 hours.

Safety Precautions

- Please use the provided charging cable and a 30W adapter (not included) to charge your devices. Otherwise, the device may not charge due to insufficient power.
- The charging plate will not work if your device's protective case is too thick. Ensure the case does not create a gap greater than 4mm between the charging pad and the back of the phone.
- The charging plate must remain unobstructed. Do not charge your phone in a metal case or with any magnetically sensitive items attached, such as metallic studs, magnetic clasps, or magnetic plates. If applicable, please remove the case before placing your phone on the charger.
- Do not insert foreign objects into the openings. Never force a cable into a charging port, and always check for obstructions.
- Do not operate the device with wet hands. To prevent electric shock, explosion, personal injury, or damage to the device, do not operate it if it has been exposed to water, moisture, or any other liquid.
- Do not leave the device unattended while charging.
- Do not leave devices on a prolonged charge. Remove them once they are fully charged.
- Do not stack this unit with other electrical or electronic devices, as this may cause overheating. Ensure the unit is completely cool before storing it in a cool, dry place.
- Do not expose the device to extreme hot or cold temperatures. Keep it away from direct heat, open flames, direct sunlight, humidity, water, and other liquids. Do not submerge the device in water.
- Do not pull, twist, or strain the power cable. Do not store the cable in a

kinked or twisted manner.

- Do not use the device if the unit or power cable is damaged. Regularly check the condition of the device and its accessories before use.
- Always unplug the unit from the adapter and let it cool sufficiently before cleaning or performing maintenance.
- Wipe the unit with a soft, damp cloth and dry it thoroughly. Do not use harsh or abrasive cleaning solvents, as these may damage the finish.
- Do not overload or overcharge the device.
- Do not store your device where it may be short-circuited by conductive materials, such as in a drawer with loose coins or keys.
- This device is not a toy. Keep it away from children and pets.
- Keep the device free from dust, lint, and debris.
- Do not drop or roughly handle your device. It is robust but not indestructible. If damaged, **DO NOT USE!**

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device (BT):

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

* RF warning for WPT :

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

According to §15.247(e)(i) and §1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.

According to KDB 447498 (2)(a)(i)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device..


Package Contents:
(1) Speaker, (1) Charging Cable, (1) User Manual
*USB Charger not included.



 **WARNING:** Cancer and Reproductive Harm
- www.P65Warnings.ca.gov

 **support: 877-543-3540**

2026 © Lifeworks Technology Group LLC. New York, NY 10018.
iHome is a registered trademark of SDI Technologies Inc., used under license. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Lifeworks Technology Group LLC. is under license. All other brands are registered trademarks of their respective companies. USB Type-C™ and USB-C™ are trademarks of USB Implementers Forum. Made in China



Double sided pritning

Accordian Style Booklet