


FRONT





MODEL: 2IHSK1017

DUOPRO 2IN1 STEREO TWS SPEAKERS

Product Specifications

Bluetooth Version: V5.4
Input: Type-C 5V/2A
Frequency Response: 100Hz - 18kHz
Bluetooth Range: >10M (Open Field)
Distortion: ≤ 5%
Speaker Power: 2*20W
Speaker Unit: 78mm (3 inches)
Battery: 7.4V/2000mA*2
Full Charge Time: 3-4 Hours

Button Functions & Interfaces


- Volume + / Next Track: Short press for volume up, long press for next track.
- Volume - / Previous Track: Short press for volume down, long press for previous track. (In Bluetooth mode, long press the "+" and "-" buttons simultaneously to disconnect TWS.)
- Ports: Type-C charging port, TF card slot, USB port, AUX audio cable jack.
- Controls: Power On/Off, Switch playback mode, Play/Pause, Turn Light On/Off.

VOLUME UP

VOLUME DOWN

TF CARD SLOT
USB-C, USB-A,
AUX PORTS

MULTIFUNCTION
POWER BUTTON



Connection and Playback

Wireless Playback
Turn on the speaker; the light flashes to indicate the Bluetooth waiting state. Open Bluetooth on your mobile phone, search for the name "iHome Duo Pro Speaker" and click connect. A beep indicates a successful connection.

TWS (True Wireless Stereo) Connection and Playback
Turn on two "iHome Duo Pro Speakers" simultaneously; they will automatically enter TWS pairing mode. Once paired, search for the Bluetooth name "iHome Duo Pro Speaker" on your phone to connect.

Note: If the speakers fail to pair automatically, disconnect the Bluetooth connection on your phone and restart both speakers to allow them to auto-reconnect.

To disconnect TWS, long press the "+" and "-" buttons simultaneously. If disconnected, two Bluetooth names will appear, allowing the devices to be used as independent speakers.

Wired & External Media Playback
AUX: Connect an AUX cable to the device and speaker to play audio.

TF Card: Insert a TF card; the speaker will beep, automatically read the card, and the blue light will flash (Supports MP3, WAV formats).

USB Drive: Insert a USB drive; the speaker will beep, automatically read the drive, and the blue light will flash (Supports MP3, WAV formats).

Button Operation Guide

Play/Pause Button:
Short press: Play/Pause music.
Long press (3 seconds): Turn Power On/Off.
Double-click: Switch Playback Mode.
Triple-click: Turn Light On/Off.

Volume/Track Controls:
"+" Button: Short press for Volume Up; Long press for Next Song.
"-." Button: Short press for Volume Down; Long press for Previous Song.

BACK



Battery & Power Maintenance

If the speaker is not used for more than 3 months, it needs to be charged before use.

Please use a charger that supports 5V/2A or the original Type-C cable for charging.

Charging Indicator: The red light is always on when charging and turns off when fully charged.

Low Voltage Warning: There will be a "beep" tone when the voltage is too low.

Safety Precautions

- The equipment complies with the standard GB 4943.1-2022.
- This product is not a toy; keep it out of the reach of children to prevent accidents.
- Do not place the machine in high-temperature environments, including direct sunlight, fire sources, or heaters. Do not use in humid or rainy environments.
- In addition to the provided charging cable, please do not use other methods to charge the machine.
- Do not disassemble the machine; prohibit any attempt to repair or modify the machine.

- Avoid dropping, impacting, scratching, or behaviors that affect the function of the machine.
- If the battery is improperly replaced, there is a risk of burning or explosion; replace only with the same type or equivalent type of battery.
- Using the audio at high volume for a long time may cause damage to your hearing.
- If there is any damage, water ingress, high-temperature deformation, abnormal sound/heat, or peculiar smells, stop using the machine immediately and contact the merchant

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

According to §15.247(e)(i) and §1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.

According to KDB 447498 (2)(a)(i)

This device contains licence-exempt transmitter(s)/receiver(s) that

comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device..


Package Contents:
(1) Speaker, (1) Charging Cable, (1) User Manual
*USB Charger not included.



 **WARNING:** Cancer and Reproductive Harm
- www.P65Warnings.ca.gov

 **support: 877-543-3540**

2026 © Lifeworks Technology Group LLC. New York, NY 10018. iHome is a registered trademark of SDI Technologies Inc., used under license. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Lifeworks Technology Group LLC. is under license. All other brands are registered trademarks of their respective companies. USB Type-C™ and USB-C™ are trademarks of USB Implementers Forum. Made in China



Double sided pritning

Accordian Style Booklet