

FRONT




Bluetooth

2-IN-1
DUOSYNC
PORTABLE SPEAKER

MODEL: 2IHSK1013

- Product Specifications**
- Bluetooth Version: V5.3
Speaker Power: Maximum: 5W*2
Frequency Response: 20HZ-20KZ
Transmission Distance: ≥ 10 meters
Battery Capacity: 1200mAh
Charging Voltage: Type-C 5V/1A
Charging Time: ≤ 3 Hours
Playback Time: > 5 Hours (at 50% volume)
Dimensions: 185 x 82 x 82mm
Weight: 485g
- Button Functions & Interfaces**
1. Power On/Off (long press for 3 seconds), Play/Pause, Answer/End Call (short press), End Call (double click).
 2. TWS Button (long press either speaker for 3 seconds after both speakers paired).
 3. Charging Port: For charging the speaker, USB-C Charging Port.
 4. Card Slot: For playing music directly from a microSD/TF card.



Charging Instructions

Low Battery Warning: When the battery is running low, the speaker will emit an alarm sound and repeat a low-battery audio reminder every 60 seconds. Please connect to a charger immediately.

Charging Status: During charging, a red LED indicator will stay continuously illuminated.

Fully Charged: Once the battery reaches 100%, the red LED indicator will turn off automatically.

Bluetooth Connection

Enter Pairing Mode: Long press the Power button for 3 seconds to turn the speaker on. The LED light will flash rapidly, indicating the speaker is ready to pair.

Connect Device: Open the Bluetooth settings on your smartphone or device, search for available devices, and tap "iHome DuoSync Speaker" to connect.

Successful Pairing: Once connected, the blue LED will stop flashing and stay on continuously.

Note: To save battery, the speaker will automatically power off if it is turned on but remains disconnected from any device for 10 minutes..

TWS MODE

While your device is connected to one of the DuoSync Speaker, press and hold the TWS button for 3 seconds on the other DuoSync Speaker to enter TWS mode

BACK



Safety Precautions

Use Approved Power: Charge only with the included Type-C cable and a certified 5v/1A power adapter to prevent battery damage.

Avoid Extreme Heat: Keep the speaker away from prolonged direct sunlight, radiators, and open flames to avoid battery hazards.

Keep It Dry: Do not expose the speaker to rain, moisture, or high-humidity environments to prevent electric shock.

Protect Your Hearing: Avoid listening at high volume levels for extended periods to prevent potential hearing damage.

No Disassembly: Do not attempt to open, repair, or modify the device; doing so voids the warranty and risks injury.

Keep Away from Children: Keep the speaker and its small accessories out of reach of young children, as they may present a choking hazard.

Safe Cleaning: Clean the exterior only with a soft, dry cloth; do not use harsh chemicals or liquid solvents.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

According to §15.247(e)(1) and §15.107(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.

According to KDB 447498 (2)(a)(1)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device..

Package Contents:
(1) Speaker, (1) Charging Cable, (1) User Manual
*USB Charger not included.

CE, RoHS, FCC, Recycle, Warning symbols

WARNING: Cancer and Reproductive Harm
- www.P65Warnings.ca.gov

support: 877-543-3540

2026 © Lifeworks Technology Group LLC, New York, NY 10018.
iHome is a registered trademark of SDI Technologies Inc., used under license. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Lifeworks Technology Group LLC is under license. All other brands are registered trademarks of their respective companies. USB Type-C™ and USB-C™ are trademarks of USB Implementers Forum. Made in China

