


EUT Internal Photographs


1.1 NG-BCP Communications Base Board (CBB)- Top View




1.2 NG-BCP Communications Base Board (CBB)- Bottom View




1.3 NG-BCP Transmit Receive Switch (TRSW) - Top View




1.4 NG-BCP Transmit Receive Switch (TRSW) - Bottom View




1.5 NG-BCP Power Amplifier Board (PA900)- Top View




1.6 NG-BCP Power Amplifier Board (PA900)- Bottom View



1.7 NG-BCP Power Supply Unit (PSU)- Top View



1.8 NG-BCP Power Supply Unit(PSU)- Bottom View




1.9 NG-BCP Radio Frequency Module (RFM)-Top View



1.10 NG-BCP Radio Frequency Module (RFM)-Bottom View



1.11 NG-BCP Display Module (LCD)- Top View



1.12 NG-BCP Display Module (LCD)- Bottom View

