

SIZE: 435x202mm
材质: 105g铜版纸四色双面印刷, 折成三页

CLOUD FRAME QUICK USER GUIDE

1

eco4life
by Aluratek

CLOUD FRAME



User Manual
Model #: CPF892

For ongoing product improvement, this manual is subject to modification without prior notice.


CLOUD FRAME QUICK USER GUIDE

2

What's-In-The Box?

- 1 Cloud Frame
- 1 User manual
- 1 Power Adaptor
- 1 Warranty card
- 1 Cloud Frame Stand

Let's Power Up!



Connect the power adaptor to an outlet to turn the frame on.

Let's download and install "eco4life" App on your phone

Download eco4life app by scanning the QR code or searching "eco4life" from app store.

Once you have installed the "eco4life" app, follow prompt to register an account, login, and start to add your cloud frame.

How to add your Cloud Frame

Step 1: Power on the cloud frame . Tap "SETTINGS" at the top of the frame screen to set up Wi-Fi connection.

Step 2: Launch the eco4life app, press "+" to start adding cloud frame. On the following screen, press "WiFi" to scan your cloud frame.




Image 1




Image 2

CLOUD FRAME QUICK USER GUIDE

3

Step 3: Use your phone to scan the QR code on the cloud frame screen. Your phone will add your frame automatically (see image 3). The cloud frame will be successfully added to your account shortly (see image 4).




Image 3




Image 4

CLOUD FRAME QUICK USER GUIDE

3

How to send photos to the frame from your phone

Open the eco4life app on your phone, select your "WiFi Frame", tap "+" button at the bottom to select photos. Pick photos you want to send to your frame, then press the "Confirm" button to start the uploading, the uploaded photos will show up on your cloud frame shortly if it is connected to Wi-Fi.



Image 1




Image 2




Image 3




Image 4

CLOUD FRAME QUICK USER GUIDE

4

How to auto power on/off the frame

Open the "eco4life" app, choose your "WiFi frame", press the "⌚" button at the bottom right corner. Tap "Add Schedule" at the bottom, pick a time that you want to auto power on/off your frame, then save it.




Image 1




Image 2




Image 3




Image 4




Image 5




Image 6

CLOUD FRAME QUICK USER GUIDE

5

How to remove a cloud frame from eco4life app

1. On your cloud frame, tap "+" at the top of the frame screen, a pop up message will show up, tap "Remove" to confirm removing the frame from your eco4life app.




Image 1

2. Meanwhile, open the eco4life app, select your "WiFi frame", tap the "⌚" on the upper right corner to edit frame setting, and tap "Remove Device" to completely delete the frame from your account.




Image 2




Image 3




Image 4

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by NEXXT SOLUTIONS may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

The transmitter must not be colocated or operated in conjunction with any other antenna or transmitter. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a Minimum distance of 20cm between the radiator and any part of your body.