


SIZE: 220X165X55mm



Battery Warnings
Important! Only adults should replace batteries.
Use alkaline batteries recommended.
Do not use rechargeable batteries.
Do not mix old and new batteries.
Do not use old, damaged, or recharged batteries.
Only batteries of same or equivalent type as recommended one to be used.
Batteries are to be inserted with correct polarity.
Exhausted batteries are not to be short circuited.
The supply terminals are not to be short circuited.
These keep this information for future reference.
Remove batteries from the product before extended storage.
WARNING: Small batteries. Hazardous if swallowed.

WARNING:
CHOKING HAZARD — Small parts.
Not for children under 3 years.

WALKIE TALKIE WATCH

CLOCK

ANTENNA

PUSH TO TALK

MAXXSPY

5+

MAXXSPY

WALKIE TALKIE WATCH



PUSH TO TALK



MAXXSPY

WALKIE TALKIE WATCH



PUSH TO TALK



WALKIE TALKIE WATCH

MAXXSPY

MAXXSPY

WALKIE TALKIE WATCH

ANTENNA

PUSH TO TALK

CLOCK



Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☑ Reorient or relocate the receiving antenna.
- ☑ Increase the separation between the equipment and receiver.
- ☑ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☑ Consult the dealer or an experienced radio/TV technician for help.

ITEM# 320128



SDE 03/CHINA H05-30



DISTRIBUTED BY
SUNNY DAYS ENTERTAINMENT, LLC
433 SE MAIN STREET, SUITE A,
SIMPSONVILLE SC 29681
MADE IN CHINA
www.sunnydaysent.com

SPECIFICATIONS, COLORS & CONTENTS MAY VARY FROM ILLUSTRATIONS.