


HIGH QUALITY BLUETOOTH HEADSET ► User Manual ◀ Model No.:V8	Product Overview  -Product Illustration- Key Instruction <table><tr><th>Name</th><th>Function</th></tr><tr><td>① "Volume +" button</td><td>Turn up the volume /play next song</td></tr><tr><td>② MFB</td><td>Power switch,play/pause, answer call, hang up, redial</td></tr><tr><td>③ "Volume -" button</td><td>Turn down the volume /play previous song</td></tr><tr><td>④ Indicator Light</td><td>Turn on :Red and blue light on for 1 second Turn off:Red light flash 3 times, Pairing: Red and blue light flash alternatively,Connected: Blue light flash every 8 seconds.</td></tr><tr><td>⑤ Microphone</td><td>Voice input</td></tr><tr><td>⑥ Interface</td><td>Lightning dock Charging</td></tr></table> -1-	Name	Function	① "Volume +" button	Turn up the volume /play next song	② MFB	Power switch,play/pause, answer call, hang up, redial	③ "Volume -" button	Turn down the volume /play previous song	④ Indicator Light	Turn on :Red and blue light on for 1 second Turn off:Red light flash 3 times, Pairing: Red and blue light flash alternatively,Connected: Blue light flash every 8 seconds.	⑤ Microphone	Voice input	⑥ Interface	Lightning dock Charging	Matching and disconnecting Pairing Steps: - For the first time, press and hold the MFB for 5 seconds to enter pairing state (Till hear prompt voice "pairing" then let go) - Activate the Bluetooth function of the mobile phone, and search the Bluetooth device. (Please read the manual of mobile phone). - Choose "V8" from the searched device list.Connection success as shown below : scan the Bluetooth devices paired devices  V8 connected  KAKA -this picture is for reference only- Disconnecting : - Turn off the Bluetooth headset (Press and hold the MFB till hear prompt voice "power off" then let go) - Turn off the Bluetooth function of the mobile phone. Remove the headset from your bluetooth list.(refer to the mobile user manual) Note: - When prompted, enter the bluetooth PIN (four zeros). - The headset automatically connects to the product that has been paired. - Turn on the bluetooth headset and press about 3S), release. -2-	Bluetooth Headset Operation Listen to Music Some functions in music player : Start the music player— Touch MFB Pause/Play— Touch MFB Turn up the volume— Click "volume +" Turn down the volume— Click "volume -" Play the next song— Press and hold "volume +" Play the previous song— Press and hold "volume -" Make a phone call We can use the Bluetooth headset button to dealing with phone calls. : Answer calls— Press MFB Hang up— Press MFB Redial— Double click MFB Turn down the volume — ntermittently tap the "volume -" Turn up the volume — Intermittently tap the "volume +" Note: - The system will restore the default volume when you restart the headset. - If the volume is too loud, it may cause damage to the eardrum. - Wear headset for a long time will affect the hearing, when there is tinnitus, nausea, dizziness, please take off the headset and have a rest. - Under the stand-by mode, the headset will automatically shut down in 10 minutes if without operation on the headset. -3-	FAQ <table><tr><td>Is the Bluetooth headset available for laptops, desktops and PDAs ?</td><td>The Bluetooth headset can be used to the device that supports the Bluetooth version and function of the headset. For specifications, please see page 6.</td></tr><tr><td>Why do I hear an echo during the call?</td><td>Adjust the volume of the headset or move to another area and try again.</td></tr><tr><td>How to clean the Bluetooth headset ?</td><td>With a dry soft cloth.</td></tr><tr><td>Why the Bluetooth headset can not be fully charged ?</td><td>The Bluetooth headset and travel charger may not be connected well, please separate the headset and travel charger, and then reconnect and charge the headset again.</td></tr><tr><td>How to switch the prompt language type ?</td><td>When you enter the pairing mode, the long press volume + is about 8S when you hear the prompt.</td></tr></table> Battery Disposal: This product contains polymer lithium battery, which is environmentally friendly and safe, please discard it according to local regulations. -4-	Is the Bluetooth headset available for laptops, desktops and PDAs ?	The Bluetooth headset can be used to the device that supports the Bluetooth version and function of the headset. For specifications, please see page 6.	Why do I hear an echo during the call?	Adjust the volume of the headset or move to another area and try again.	How to clean the Bluetooth headset ?	With a dry soft cloth.	Why the Bluetooth headset can not be fully charged ?	The Bluetooth headset and travel charger may not be connected well, please separate the headset and travel charger, and then reconnect and charge the headset again.	How to switch the prompt language type ?	When you enter the pairing mode, the long press volume + is about 8S when you hear the prompt.	Safety Rule - Please use the mobile phone and headset correctly while driving, and follow the local regulations to ensure traffic safety. - Small parts may cause a choking hazard, please keep out of reach of children. - Pay attention to the instructions of designated area and use the mobile phone and headset as required (e.g. hospital, aircraft, blasting range, etc.). - Do not hang or store the headset near any air bag, it may cause serious personal injury when the air bag is unfolded. - Do not disassemble or destroy the built-in battery. Specification Bluetooth Version: V4.1 Operation Range:10M Battery: 50mAh Frequency: 2.4GHz Stand-by Time: about 50 hrs Charging time:about 1.5 hrs Music Time: about 3 hrs -5-	NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: - this device may not cause harmful interference, and. - this device must accept any interference received, including interference that may cause undesired operation. -6-
	Name	Function																												
	① "Volume +" button	Turn up the volume /play next song																												
	② MFB	Power switch,play/pause, answer call, hang up, redial																												
	③ "Volume -" button	Turn down the volume /play previous song																												
④ Indicator Light	Turn on :Red and blue light on for 1 second Turn off:Red light flash 3 times, Pairing: Red and blue light flash alternatively,Connected: Blue light flash every 8 seconds.																													
⑤ Microphone	Voice input																													
⑥ Interface	Lightning dock Charging																													
Is the Bluetooth headset available for laptops, desktops and PDAs ?	The Bluetooth headset can be used to the device that supports the Bluetooth version and function of the headset. For specifications, please see page 6.																													
Why do I hear an echo during the call?	Adjust the volume of the headset or move to another area and try again.																													
How to clean the Bluetooth headset ?	With a dry soft cloth.																													
Why the Bluetooth headset can not be fully charged ?	The Bluetooth headset and travel charger may not be connected well, please separate the headset and travel charger, and then reconnect and charge the headset again.																													
How to switch the prompt language type ?	When you enter the pairing mode, the long press volume + is about 8S when you hear the prompt.																													