



MODEL: RS9113SB

FW:NB0-S0W

FCC:XF6-RS9113SB

IC:8407A-RS9113SB

LC:I05-3314



Label Diagram



Label Location