

User Manual

Bluetooth Speaker



Model name: ESB106BL
Trand name: E-matic
FCC ID: XHWESB106
Quick Start Guide

English

Français

Speaker Basics

- Power Button. Press and hold to turn on the speaker.
- Answer calls directly from the speaker.
- Previous Track / Rewind
- Next Track / Fast Forward
- Play/Pause
- Decrease Volume
- Increase Volume

Turn on the Speaker

- OFF ON
Slide the switch on the back of the speaker to ON.
- Press and hold the power button on the top of the speaker.

A blue LED on the front of the speaker will begin blinking and a voice will indicate the speaker is on.

Pairing with your Device

- Turn on the speaker. The status light will blink fast if unconnected, slow if connected.

iOS®

- Go to Bluetooth Settings. Be sure Bluetooth is active, and tap Blitzspeaker.
- "Connected" will display next to Blitzspeaker.

Android™ 4.0/4.4

- Enter the settings app located in the apps menu and turn on Bluetooth.
- Tap Search for Devices.
- Tap Blitzspeaker to connect.

Phone Calls

Receive phone calls when connected through Bluetooth (audio playback will pause during calls)

While connected to Bluetooth, answer calls pressing the Call button on top of the speaker.

Answer/End calls:
Press the button.

While on a call:
Short press the button to answer.

Ignore call:
Long press the button to ignore a call.

Redial call:
Long press the button.

Playing Media

Using Bluetooth

- Make sure Bluetooth is on and connected to the Speaker.
- Select a song/video. Speaker will automatically sync to your device.

Using AUX Cable



Plug the cable from your device to the AUX port on the back of the speaker.

Using MicroSD



Insert a MicroSD card into the slot on the back of the speaker. Control playback with the buttons on the top of the speaker.

Charging



To charge the speaker plug the provided USB Cable to the USB port on the back of the speaker. Then connect to a computer or USB charger.

While charging, the status light will glow solid RED. The light will turn off when charging is complete.

Battery life is approximately 15 hours at moderate listening levels.

Customer Support

Visit ematic.us/support for customer support regarding your device.

To submit a request, fill out the required information online. You will be provided a ticket number regarding your issue which you can refer to when contacting us further.

©2014 Ematic, iPad®, iPhone® and iPod® touch are registered trademarks of Apple Inc. iOS is a trademark of Cisco Technology, Inc. Android is a trademark of Google Inc. The Bluetooth® word mark, figure mark (stylized "B Design"), and combination mark (Bluetooth word mark and "B Design") are registered trademarks and are wholly owned by the Bluetooth SIG and used by Ematic under a license. Ematic is not affiliated with Apple, Inc. Cisco Technology, Inc. or Google, Inc., (including Android). The Ematic brand and products are owned by Shaghat, Ltd.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.