

Android POS Terminal Model-Z600 Quick start guide	Thanks for your purchase of Product Description. Please read this guide first before you use the device,and it will ensure your safety and the proper use of equipment.About the equipment configuration, please check with the relevant contracts of the device or consult the seller who sells the equipment to you. The pictures in this guide are for reference only, if some pictures do not match the physical product, please in kind prevail.Many network function which is described in this manual is the specific service by the network service providers. Whether use these functions,it depends on the Internet service provider who services for you. Without the company's permission, anyone should not use any forms or any ways to copy, excerpts,backup,modify,spread,translated into other languages,all or partly used for commercial Indicator icon Warning: may hurt themselves or others Caution: may damage your equipment or other devices Note: the annotations, use hints or additional information	Toknowtheproduct 1 Front view  2 Back View 	Charging for the battery Before using the device for the first time or the battery for a long time did not make Unavailable,you must first to charge the battery.  Only use the company matching chargers, battery and data cables.Using the charger or data cable without permission will cause the battery explosion or will damage the equipment.In the condition of charging, LED light shows red;When the LED light shows green,it expresses that the battery has been completed; Boot/Shutdown the machine When you boot up the device,Please install the battery. Then wait for some time, when it appears the boot screen,it will lead the progress to complete and go into Android operating system.It needs a certain period of time at the beginning of the equipment initialization,so please kindly wait for it patiently. When shutdown the device, please remove the battery
FCC RF Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To comply with FCC RF Exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for the transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. Using the touchscreen Click Touch once, select or open the function menu, options or 	FCC Regulations: - This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. - This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/ TV technician for help. - Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.	Use Notes The operating environment - Please do not use this device in the thunderstorm weather, because the thunderstorm weather may result in the equipment failure, or click the danger. - Please put the equipment from rain, moisture and liquids containing acidic substances, or it will make the electronic circuit boards corrosion. - Don't store the device in overheating, high temperature, or it will shorten the life of electronic devices. - Don't store the device in a too cold place, because when the device's temperature rises, moisture can form inside, and it might damage the circuit board. - Do not attempt to disassemble the device, non-professional personnel handling can damage it. - Do not throw, beat or intense crash the device, because rough treatment will destroy the device's parts, and it may cause the device failure. Children's health - Please put the device, its components and accessories in the place where children can't touch. - This device is not toys, so children should be under adult supervision to use it. The charger security - When charging the device, power sockets should be installed near the device and should be easy to hit. And the areas must be far away from the debris, flammable or chemicals. - Please do not fall or crash the charger. When the charger shell is damaged, please ask the vendor for replacement. - If the charger or the power cord is damaged, please do not continue to use, so as to avoid electric shock or fire.	- Please do not fall or crash the charger. When the charger shell is damaged, please ask the vendor for replacement. - Please do not use wet hand to touch the power cord, or with power supply cable way out the charger. - The charger must meet the "2.5 restricted power" in the request of the standard <GB4943.1 information technology equipment safety - If the device needs to connect USB port, please make sure the SUB contains USB port - IF logo and its performance is in accordance with the relevant specification of the USB - IF. The battery safety - Do not use the battery short circuit, or use a metal or other conductive objects to contact with the battery terminal. - Please do not disassemble, squeeze, twist, pierce or cut the battery. - Please do not insert foreign body in the battery, contact the battery with water or other liquid, make the cells exposed to fire, explosion or other risk sources. - Do not put or store the battery in high temperature environment. - Please do not put the battery in a microwave or in the dryer. Please do not throw the battery into the fire. - If there is a battery leak, do not let the liquid on the skin or eyes, and if accidentally touched, please rinse with plenty of water, and seek for medical advice immediately. - When a device in standby time obviously shorter than in the normal time, please replace the battery Repair and Maintenance - Don't use strong chemicals or powerful detergent to clean the device. If it is dirty, please use a soft cloth to clean the surface with a very dilute solution of glass cleaner. - Screen can be wiped with alcohol cloth, but be careful not to let the fluid accumulate around the screen. Dry the display with a soft non-woven cloth immediately, in order to prevent the screen from leaving the strip traces.