

2. Change the Frequency

Under FM sound output, press “+” or “-” to increase or reduce the frequencies. Press and hold the “+” or “-” key to skip frequencies.

- The instruction of charging:
 1. When BLUETOOTH WITH FM MODULATOR lack power, the indicator light will flashes twice every 5 seconds, and sound “Doo” alarm voice every minute. Please charge for BLUETOOTH WITH FM MODULATOR .
 2. When BLUETOOTH WITH FM MODULATOR is charging, the indicator light flashes slowly.
 3. When the battery fully charged, the indicator light will bright on.
 4. The BLUETOOTH WITH FM MODULATOR only can be charged at Bluetooth standby mode.

- **Main parameters of BTFM-08**

Output voltage of the charger: DC5V.

Maximum output current of the charger: 1.5A.

Working temperature: 0~50 Celsius degree.

FM frequency: 88.1-107.9 MHz.

Bluetooth edition: 2.0;

Bluetooth Support: HSP(Headset Profile), HFP(Hands Free Profile), A2DP(Advance Audio Distribution Profile) and AVRCP (Audio Video Remote Control Profile) function.

Bluetooth transmission distance: 5M

Support Format: MP3 (optional) and WMA format file.

Frequency response: 20Hz~15 KHz.

Battery: standard Lithium battery of Nokia (BL-5B)

LCD display: 112*16



WIRELESS FM MODULATOR



WIRELESS FM MODULATOR

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

BLUETOOTH WITH FM MODULATOR

- **On/Off**

1. Turn on:

Install the battery, the power switch ON / OFF status playing at ‘ON’, and then BLUETOOTH WITH FM MODULATOR will turn on.

2. Turn off:




In the status of ‘ON’, switch ON/OFF status at “OFF”, BLUETOOTH WITH FM MODULATOR will be turn off (Not plug the charger state)


- **Program to connect with the mobile phone:**

1. Put BLUETOOTH WITH FM MODULATOR and mobile phone on the location less than 2 meters apart.
2. <a> If BLUETOOTH WITH FM MODULATOR is connecting with other Bluetooth devices. Please switch “ON/OFF” to be “OFF”, and then switch to “ON”, there will be a voice to say “Please enter pin code 0000”, and the indicator light flashes fast.
- If BLUETOOTH WITH FM MODULATOR isn’t connected with other Bluetooth devices. Please follow up the operations as below:
3. According to manual of mobile phone, active the Bluetooth function and then searching for Bluetooth earphone.
4. Choose ‘Dellking’ Bluetooth device, input pair code <0000>, then press “confirm” button to pair BLUETOOTH WITH FM MODULATOR, the indicator light will go to flash regularly, here comes “Di” sound. It indicates BLUETOOTH WITH FM MODULATOR has paired with mobile phone successfully.
5. BLUETOOTH WITH FM MODULATOR can only pair with one mobile phone in one time. It must cut down one connection to pair another one.
6. At pairing status, the indicator light flashes rapidly.


- **The Use of In-Car Bluetooth**

1. Answer call


When calls coming, press  key on BLUETOOTH WITH FM MODULATOR to answer, also can answer by BLUETOOTH WITH FM MODULATOR. If you want to change to answer by mobile phone, then press  key to Switch to confidential conversation (By Mobile phone). Press  to answer by again.

2. Answer call on stereo playing
If there is phone call comes when music playing via stereo, press  key to answer. BLUETOOTH WITH FM MODULATOR will play music automatically after hang up the call.

3. End up Calling

Press  key on BLUETOOTH WITH FM MODULATOR or the “hang up” key on mobile phone to end call.


4. Rejecting the call

Press  key to reject the phone call.


5. Dialing

Use mobile phone to dial

6. Voice Dialing

Press  shortly to start up voice dialing function (It only can be used when mobile phone support voice dialing).

7. Re-dial the last number

Press and hold  until heard “Di” then release. It will dial the last number dialed out before.

8. Play stereo music with Bluetooth

After Bluetooth paired successfully, use mobile phone play music can realize stereo playing, and transmit music to car FM tuner.

- **Music Control function**

1. Switch music playing through mobile phone Bluetooth stereo, USB device and SD card.

Press and hold “Play/Pause” until hear “Di” sound then release it to realize switch music playing through Bluetooth stereo/USB device/SD card.

2. Play/Pause key

Press “Play/Pause” to stop playing when BLUETOOTH WITH FM MODULATOR playing music, press it again to start.

3. Next song

Press “▶▶” shortly to skip or choose next song.

4. Last song

Press “◀◀” shortly to back up or choose last song.

5. Adjust the volume

Press and hold “◀◀” or “▶▶” key to decrease or increase the volume of stereo playing or conversation (Press “◀◀” or “▶▶” shortly to reduce or increase the conversation volume when talking).

6. Choose the language

At turning on status, double click “CH” key will hear indicator voice “Mandarin” or “British English”, choose one to realize Chinese Voice Dialing or English Voice Dialing.

- **FM Control function:**

1. Switch between Speaker and FM

At turning on status, press “CH” key to switch sound between Speaker and FM