

BOOX





Customer support center:
<https://www.boox.com/support/>
Email: help@boox.com

Made in China
©Onyx International Inc. All rights reserved.

BOOX Max Lumi2

Quick Start Guide
快速说明书

For further instructions, please learn from the pre-loaded
User Manual or official website technical support.
www.boox.com



English

- ① Power ② Fingerprint recognition ③ USB-C Port
④ Dual Mic ⑤ Dual Speakers

- a. BOOX Device b. Warranty Card c. Quick Start Guide
d. Stylus Pen e. USB-C Cable

QUICK START GUIDE

Turn on the device: Hold down the power button for 2~3 second.

Charging: When you see a low battery alter or cannot turn on the device, charge it by connecting to the PC or power supply with an adapter. The indicator light will be on when the device is charging, and will be off after the battery is fully charged.

Firmware update: Download the update packages to the root directory of the local storage, or get OTA updates on the device.

To force shutdown, please hold the power button for about 8 seconds.

You can read the full version of the User Manual on the official BOOX website:
<https://www.boox.com/downloads/>

日本語

- ① 電源ボタン ② 指紋認識 ③ USB-Cスロット
④ デュアルスピーカー ⑤ デュアルスピーカー

- a. BOOX 本体 b. 保証書カード c. クイックスタートガイド
d. スタイラス e. USB-C ケーブル

クイックスタートガイド

本体の電源を入れます。電源ボタンを2~3秒長押ししてください。

充電: 「ローバッテリー」と表示される、もしくは本体の電源が入らない場合は、パソコンかコンセントに接続して充電を行って下さい。本体の充電中はインジケータが点灯し、その後フル充電されると消灯します。

ファームウェアアップデート: アップデートインストーラーパッケージを本体ストレージのルートディレクトリにダウンロードするか、デバイス上でOTAアップデートを行なって下さい。

強制的にシャットダウンを行なうには、電源ボタンを8秒程度長押しして下さい。

ユーザーマニュアルのフルバージョンは BOOX ウェブサイトで入手することができます:
<https://www.boox.com/downloads/>

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

This device complies with RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

